

# Service manual for SAF axles and Suspension Assemblies



Edition 8/2002



Manufacturer.....


Address.....

Body type.....

Chassis no.....

Year of manufacture.....

Registration, date-in-service.....



### Spare parts service for SAF axles and suspension systems

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.

Please enter the axle identification figures in the type plates shown below so that correct specification are available when required.

### Type plate for axle beam assembly

|   |          |  |       |
|---|----------|--|-------|
| <b>SAF</b>                                |          | OTTO SAUER ACHSENFABRIK KEILBERG<br>D-63854 BESSENBACH / G E R M A N Y |       |
| TYP                                       |          |  |       |
| Ident.-No.<br>/Prod.-No.                  |          |  |       |
| zul. Last kg<br>perm. cap.<br>charge adm. |          | STAT.  | TECH. |
|   |          | v max. km/h<br>max. speed<br>vitesse maxi.                             |       |
| TDB-No.                                   | Grundtyp |  |       |

|  | Page  |
|--|-------|
| SAF axle identification.....   | 2     |
| General service instructions.....  | 5     |
| Notes .....  | 53-54 |
| <b>SAF axle types SK RS/RZ 9042/11242/9037/11037</b>                           |       |
| Service schedule for SAF axle types SK RS/RZ 9042/11242.....                   | 6     |
| Service chart for SAF axle types SK RS/RZ 9042/11242.....                      | 7     |
| Spare parts and torque wrench settings SK RS/RZ 9042/11242.....                | 8-9   |
| Service schedule for SAF axle types SK RS/RZ 9037/11037.....                   | 10    |
| Service chart for SAF axle types SK RS/RZ 9037/11037.....                      | 11    |
| Spare parts and torque wrench settings SK RS/RZ 9037/11037.....                | 12-13 |
| <b>SAF axle types SK RS/RZ 9030/11030 / RZ 12030</b>                           |       |
| Service schedule for SAF axle types SK RS/RZ 9030/11030 / RZ 12030.....        | 14    |
| Service chart for SAF axle types SK RS/RZ 9030/11030 / RZ 12030.....           | 15    |
| Spare parts and torque wrench settings SK RS/RZ 9030/11030 / RZ 12030.....     | 16-17 |
| <b>SAF axle types SK RS/RZ 12242</b>   |       |
| Service schedule for SAF axle types SK RS/RZ 12242.....                        | 18    |
| Service chart for SAF axle types SK RS/RZ 12242.....                           | 19    |
| Spare parts and torque wrench settings SK RS/RZ 12242.....                     | 20-21 |
| <b>SAF axle types K RS/RZ 14242/16242</b>                                      |       |
| Service schedule for SAF axle types K RS/RZ 14242/16242.....                   | 22    |
| Service chart for SAF axle types K RS/RZ 14242/16242.....                      | 23    |
| Spare parts and torque wrench settings K RS/RZ 14242/16242.....                | 24-25 |
| <b>SAF axle types with disc-brakes SK RS/RZ 9022K/11222K/9019K/11019K</b>      |       |
| Service schedule for SAF axle types SK RS/RZ 9022K/11222K/9019K/11019K.....    | 26    |
| Service chart for SAF axle types SK RS/RZ 9022K/11222K/9019K/11019K.....       | 27    |
| Spare parts and torque wrench settings SK RS/RZ 9022K/11222K/9019K/11019K..... | 28-29 |
| <b>Trailing steering axles</b>   |       |
| Trailing steering axles - adjustment .....                                     | 30-31 |
| Spare parts and torque wrench settings SK RLS 9042/11242.....                  | 32-33 |
| Spare parts and torque wrench settings SK R LZ 9037/11037.....                 | 34-35 |
| Spare parts and torque wrench settings SK R LZ 9030/11030.....                 | 36-37 |
| Spare parts and torque wrench settings<br>Air Suspension Series M.....         | 38-39 |
| Spare parts and torque wrench settings<br>Air Suspension Series O.....         | 40-41 |
| Spare parts and torque wrench settings<br>Air Suspension Series U.....         | 42-43 |

## General information

|   |       |
|---|-------|
| Tightening instruction for pivot clamping bolt assembly ..... | 44    |
| Adjusting the ride height .....                               | 45    |
| Braking system - checking and adjustment .....                | 46    |
| HALDEX automatic slack adjuster.....                          | 47-48 |
| S-ABA automatic slack adjuster.....                           | 49    |
| Track control.....  | 50    |
| Wheel bearings - adjustment .....                             | 51    |
| Torque wrench settings.....                                   | 52    |

## for SAF axles and suspension units

### 1. Instructions and tips for vehicle operation

In order to maintain the operation and road safety of the vehicle, the maintenance operations prescribed by SAF must be carried out regularly at the specified intervals (see "Maintenance instructions").

#### Furthermore, ensure that

- 1.1 the disc brake is not overheated due to continuous operation as otherwise irreparable damage to the surrounding components – in particular the wheel bearings – cannot be ruled out. This can impair the operational and road safety of the vehicle and represent a serious hazard for man and machine.
- 1.2 the compatibility of the brakes on the truck-trailer combination is checked. For reliable braking and uniform brake lining wear, the brake systems of the two vehicles must be matched to one another before starting operation
- 1.3 the parking brake is not applied immediately when the brakes are hot as the resulting different stress fields can damage the brake discs
- 1.4 the drum brakes are not overheated as this will result in a dangerous reduction in braking efficiency
- 1.5 the maximum permissible axle loads and speeds are not exceeded
- 1.6 the cargo is evenly distributed over the loading area and safely secured
- 1.7 on vehicles with air suspension, the air bags are always fully pressurised before starting a journey
- 1.8 the prescribed wheel rims and tyre sizes are employed
- 1.9 the tyres have the prescribed inflation pressure
- 1.10 your driving style is matched to the road conditions
- 1.11 axle supports are used when loading/unloading construction machinery
- 1.12 the use of auxiliary trailer braking facilities (trailer underrun brake) is not permitted.

### 2. Vehicle safety

- 2.1 The daily check of the vehicle for road safety before starting a journey is the responsibility of the driver.
- 2.2 Modifications to the suspension and braking system are strictly forbidden.
- 2.3 Compliance with the specified permissible axle loads, specifications in the vehicle operating permit, vehicle inspection intervals and the regular maintenance intervals is the responsibility of the vehicle owner.
- 2.4 We strongly recommend fitting only SAF approved replacement parts and spare parts which are covered by SAF product liability. These products have been thoroughly tested by SAF for safety, functionality and suitability. Fitting of these parts guarantees not only safety on the roads but satisfies the legal operational requirements. SAF is not in a position to judge whether those products from other companies represent a safety risk for SAF axles and systems.

### 3. Warranty

- 3.1 Warranty claims will only be accepted as long as the operating and maintenance instructions have been complied with and if SAF approved spare parts have been fitted.
- 3.2 Warranty claims must be reported to SAF before starting the work.
- 3.3 The warranty period is 12 months after the vehicle registration date or after the start of operation of the vehicle.

### 4. Service and spare parts

A close-knit service network of SAF partner companies is at your disposal for technical advice on SAF axles and suspension systems as well as for supplying approved SAF spare parts (see back cover or brochure "SAF service stations").

**In case of repair we strongly recommend fitting only SAF original parts for those reasons mentioned in point 2.4.**

SAF axles and suspension units are subject to continuous further development; the data and drawings contained in the manual may therefore differ from the details given in the operating permit.

The contents of the manual does not constitute the basis for a legal claim.

Reprinting, reproduction or translation in whole or in part is not permitted.

The issue of this publication invalidates all earlier maintenance and repair manuals.

## for SK RS/RZ 9042/11242 axles and suspension units (steering axle see p. 30-33)

| Service schedule      | Mileage intervals > | Periodic checks         |                 |                 |                  |
|-----------------------|---------------------|-------------------------|-----------------|-----------------|------------------|
|                       |                     | After first 5,000 km or | every 30,000 km | every 90,000 km | every 150,000 km |
| whichever comes first | Time intervals >    | after first month       | every 3 months  | every 6 months  | every 12 months  |

### Mechanical check

|   |   |  |  |   |
|---|---|--|--|---|
| <b>Note:</b><br>Torque check wheel nuts after the first 50 km and 150 km (and after every wheel removal).   |   |  |  |   |
| Torque check all nuts and bolts to recommended setting.   | • |  |  | • |
| Hub end-float adjustment not required.<br>Pack wheel bearings with fresh grease after 500,000 km or 50 months, whichever comes first. Check condition of taper roller bearings and replace, if necessary. |   |  |  |   |
| Lubricate camshaft bearings after every brake lining replacement, however, at least every 12 months.  |   |  |  |   |

### Visual inspection for wear/damage

|   |   |   |  |  |
|---|---|---|--|--|
| Check suspension components for wear, fluid leakage and damage<br>Check brake linings for wear<br><b>Check camshafts for free movement</b><br>Check slack adjusters for correct function<br>Check braking system for leaks (brake applied)<br>Check air suspension for air leaks<br>Check air suspension bellows for damage<br>Check piston surface for contamination and clean, if necessary<br>Check parabolic springs for damage, scoring and corrosion<br>Check self steering axle for correct function<br>Check tyre wear and tracking (if required) | • | • |  |  |
|---|---|---|--|--|

### Safety inspection

|  |   |   |  |   |
|--|---|---|--|---|
| Check wheel brakes for correct adjustment<br>Check service brake and hand brake efficiency   | • | • |  |   |
| Check truck-trailer combination for brake compatibility<br>Check service brake pressure to manufacturer's recommendation                                       | • |   |  | • |
| Check air suspension for correct ride height.<br>With 2 levelling valves, the max. permissible bellows pressure difference (LH to RH vehicle side) is 0.2 bar. | • | • |  |   |

### Special service conditions

|   |                                       |
|---|---------------------------------------|
| Vehicles with long standing periods:    | service at specified time intervals   |
| Vehicles used under extreme conditions: | service at suitably reduced intervals |

**Warranty claims will only be accepted as long as the operating and maintenance instructions have been complied with and if SAF approved spare parts have been fitted.**

## for SK RS/RZ 9042/11242 axles


### Hub end-float setting. Lubricant.

Hub end-float adjustment is not required.  
 Pack wheel bearings with fresh grease after 500,000 km or 50 month, whichever comes first.  
 Check condition of taper roller bearings and replace, if necessary.  
 Replace O-ring (39) and fit the wheel cap.  
 After brake relining, lubricate camshaft bearings whilst rotating the camshaft through 360° several times.  
 Do not disassemble the wheel bearing assembly.  
 Use a vacuum cleaner to remove brake dust.  
 Never use pressurised cleaning devices or cleaning fluids on the brake drum and hub.  
 Clean stub axle and apply fresh SAF fitting paste.


### Lubricant specification:

Wheel bearings:  
 SAF parts no. 4 387 0011 05  
 Camshaft:  
 SAF parts no. 4 387 0011 05  
 Stub axle:  
 SAF parts no. 4 387 0015 06  
 SAF fitting paste  
 Brake anchor bracket ball:  
 SAF parts no. 4 387 0007 00  
 Copper paste

### Hub nut tightening



LH direction of travel - LH thread.  
 RH direction of travel - RH thread.  
 Pretighten to 150 Nm whilst rotating drum.  
 For final torque, continue tightening through one more scale line (10°).  
 Hub nuts with LH threads are marked with a groove milled into the hex outside.



### BRAKE type SNK 420

Max. permissible turned brake drum bore: 424.0 mm  
 Brake drum bore with max. permissible wear: 425.0 mm  
 SAF approved brake linings: BERAL 1541, BREMSKERL 6386  
 Turn new brake linings to brake drum bore dimension + 0.3 mm.  
 When renewing rivets, observe the manufacturer's instructions regarding the brake lining.

| Brake size | SAF parts no, brake lining     | Brake drum/brake lining refacing stages in mm |                       |                       | Brake linings | Rivets | DIN 7338 rivet |
|------------|--------------------------------|---|-----------------------|-----------------------|---------------|--------|----------------|
|            |                                | Nominal size                                  | 1st oversize          | 2nd oversize          |               |        |                |
| SNK 420    |                                | d <sub>0</sub> -420.0                         | d <sub>1</sub> -422.0 | d <sub>2</sub> -424.0 |               |        |                |
| x 180      | 1 057 0060 00<br>1 057 0061 00 | 20.6<br>20.0                                  | 21.6<br>21.0          | 22.6<br>22.0          | 4             | 64     | B 8 x 15       |
| x 200      | 1 057 0066 00<br>1 057 0067 00 | 20.6<br>20.0                                  | 21.6<br>21.0          | 22.6<br>22.0          |               |        |                |

### Assembly tools 9042/11242

Hub nut spanner  
 Brake shoe clamping device  
 Brake drum fixing flanges  
 Wheel bearing inserter

### SAF parts no.

1 012 0024 00  
 3 349 1001 00  
 3 434 1040 01  
 3 434 1043 00


## Exploded view of SK RS/RZ 9042/11242 axle assembly Torque wrench settings

Use torque wrench.  
The use of impact wrenches is not accepted.

**Wheel nuts:**  
Spigot-hub-centred fixing:  
M 22 x 1.5 / 600 Nm  
Bolt-centred fixing:  
M 22 x 1.5 / 430 Nm

**U-bolts:**  
(diagonally in three stages)  
M 24 / 700 Nm  
M 22 / 650 Nm  
M 20 / 500 Nm

**Shock absorber:**  
M 24 / 400 Nm





## SK RS/RZ 9042/11242

| Item | Parts designation  | Item | Parts designation  |
|------|--|------|--|
| 01   | <b>Axle beam assembly</b><br>including items 3 - 6, 010, 19,<br>22 - 22.1, 25              | 64   | <b>Brake shoe assembly</b><br>including items 65, 71 - 73          |
| 3    | Spherical mounting plate   | 65   | Brake shoe with item 66  |
| 4    | Protection plug  | 66   | Cam roller   |
| 4.1  | Protection plug (axle tube)  | 70   | <b>Lining service group</b><br>including items 71, 72, 73          |
| 5    | Ball   | 71   | Brake lining, cam roller side                                      |
| 6    | Camshaft bearing, brake carrier side   | 72   | Brake lining, ball side  |
| 6.1  | Riffle bolt  | 73   | Rivet  |
| 6.2  | Hex nut  | 74   | Spring clip  |
| 010  | <b>Camshaft bearing assembly,</b><br>linkage adjustment side<br>including items 12, 15, 18 | 75   | Return spring  |
| 12   | Camshaft bearing   |      | <u>with ABS</u>  |
| 15   | Hex bolt   | 76   | Bracket sensor   |
| 18   | Bellows  | 76.2 | Hex bolt   |
| 18.3 | Brake lining wear gauge  | 78   | ABS sensor   |
| 19   | O-ring - Hub nut   | 081  | <b>Camshaft assembly (LH)</b><br>including items 18.3, 85.1 - 88.1 |
| 20   | O-ring - Stub axle   | 082  | <b>Camshaft assembly (RH)</b><br>including items 18.3, 85.1 - 88.1 |
| 22   | Hub nut, RH thread   | 85.1 | Disc spring  |
| 22.1 | Hub nut, LH thread   | 86   | Spring clip  |
| 25   | Brake cylinder support   | 87   | Washer   |
| 27   | Hub unit, complete<br>with item 27.2   | 88   | Washer   |
| 27.2 | Repair kit including items<br>27.3, 38 - 39  | 88.1 | Spring clip  |
| 27.3 | Bearing grease   |      | <u>with automatic adjustment</u>                                   |
| 29   | Brake drum   | 89.1 | Automatic slack adjuster   |
| 30   | <b>Wheel bolt assembly</b><br>including items 31 - 34                                      | 89.2 | Anchor plate, RH   |
| 31   | Riffle bolt  | 89.3 | Anchor plate, LH   |
| 34   | Wheel nut  | 90   | Return spring  |
| 38   | Inner seal ring  | 091  | <b>Dust cover assembly</b><br>including items 92 - 98, 99          |
| 38.1 | Outer seal ring  | 92   | Dust cover, RH   |
| 39   | O-ring - Hub cap   | 93   | Dust cover, LH   |
| 40   | Hub cap, complete with items 39, 41  | 94   | Plug   |
| 40.1 | Hub cap, complete with pole wheel<br>and items 39 - 41                                     | 95   | Cable clamp  |
| 41   | Plug   | 96   | Hex bolt   |
| 059  | <b>Brake assembly</b><br>including items 64, 74 - 75                                       | 97   | Clamp  |
|      |  | 98   | Plug   |
|      |  | 99   | Rubber grommet, ABS  |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.

## for SK RS/RZ 9037/11037 axles and suspension units (steering axle see p. 34-35)

| Service schedule      | Mileage intervals > | Periodic checks         |                 |                 |                  |
|-----------------------|---------------------|-------------------------|-----------------|-----------------|------------------|
|                       |                     | After first 5,000 km or | every 30,000 km | every 90,000 km | every 150,000 km |
| whichever comes first | Time intervals >    | after first month       | every 3 months  | every 6 months  | every 12 months  |

### Mechanical check

|   |   |  |  |   |
|---|---|--|--|---|
| <b>Note:</b><br>Torque check wheel nuts after the first 50 km and 150 km (and after every wheel removal).   |   |  |  |   |
| Torque check all nuts and bolts to recommended setting.   | • |  |  | • |
| Hub end-float adjustment not required.<br>Pack wheel bearings with fresh grease after 500,000 km or 50 months, whichever comes first. Check condition of taper roller bearings and replace, if necessary. |   |  |  |   |
| Lubricate camshaft bearings after every brake lining replacement, however, at least every 12 months.  |   |  |  |   |

### Visual inspection for wear/damage

|   |   |   |  |  |
|---|---|---|--|--|
| Check suspension components for wear, fluid leakage and damage<br>Check brake linings for wear<br><b>Check camshafts for free movement</b><br>Check slack adjusters for correct function<br>Check braking system for leaks (brake applied)<br>Check air suspension for air leaks<br>Check air suspension bellows for damage<br>Check piston surface for contamination and clean, if necessary<br>Check parabolic springs for damage, scoring and corrosion<br>Check self steering axle for correct function<br>Check tyre wear and tracking (if required) | • | • |  |  |
|---|---|---|--|--|

### Safety inspection

|  |   |   |  |   |
|--|---|---|--|---|
| Check wheel brakes for correct adjustment<br>Check service brake and hand brake efficiency   | • | • |  |   |
| Check truck-trailer combination for brake compatibility<br>Check service brake pressure to manufacturer's recommendation                                       | • |   |  | • |
| Check air suspension for correct ride height.<br>With 2 levelling valves, the max. permissible bellows pressure difference (LH to RH vehicle side) is 0.2 bar. | • | • |  |   |

### Special service conditions

|   |                                       |
|---|---------------------------------------|
| Vehicles with long standing periods:    | service at specified time intervals   |
| Vehicles used under extreme conditions: | service at suitably reduced intervals |

**Warranty claims will only be accepted as long as the operating and maintenance instructions have been complied with and if SAF approved spare parts have been fitted.**

## for SK RS/RZ 9037/11037 axles


### Hub end-float setting. Lubricant.

Hub end-float adjustment is not required.  
 Pack wheel bearings with fresh grease after 500,000 km or 50 month, whichever comes first.  
 Check condition of taper roller bearings and replace, if necessary.  
 Replace O-ring (39) and fit the wheel cap.  
 After brake relining, lubricate camshaft bearings whilst rotating the camshaft through 360° several times.  
 Do not disassemble the wheel bearing assembly.  
 Use a vacuum cleaner to remove brake dust.  
 Never use pressurised cleaning devices or cleaning fluids on the brake drum and hub.  
 Clean stub axle and apply fresh SAF fitting paste.


### Lubricant specification:

Wheel bearings:  
 SAF parts no. 4 387 0011 05  
 Camshaft:  
 SAF parts no. 4 387 0011 05  
 Stub axle:  
 SAF parts no. 4 387 0015 06  
 SAF fitting paste  
 Brake anchor bracket ball:  
 SAF parts no. 4 387 0007 00  
 Copper paste

### Hub nut tightening



LH direction of travel - LH thread.  
 RH direction of travel - RH thread.  
 Pretighten to 150 Nm whilst rotating drum.  
 For final torque, continue tightening through one more scale line (10°).  
 Hub nuts with LH threads are marked with a groove milled into the hex outside.



### BRAKE type SNK 367

Max. permissible turned brake drum bore: 371.0 mm  
 Brake drum bore with max. permissible wear: 372.0 mm  
 SAF approved brake linings: BERAL 1561, BREMSKERL 6386  
 Turn new brake linings to brake drum bore dimension + 0.3 mm.  
 When renewing rivets, observe the manufacturer's instructions regarding the brake lining.

| Brake size | SAF parts no. brake lining     | Brake drum/brake lining refacing stages in mm |                       |                       | Brake linings | Rivets | DIN 7338 rivet |
|------------|--------------------------------|---|-----------------------|-----------------------|---------------|--------|----------------|
|            |                                | Nominal size                                  | 1st oversize          | 2nd oversize          |               |        |                |
| SNK 367    |                                | d <sub>0</sub> -367.0                         | d <sub>1</sub> -369.0 | d <sub>2</sub> -371.0 |               |        |                |
| x 180      | 1 057 0068 00<br>1 057 0069 00 | 21.1<br>20.5                                  | 22.1<br>21.5          | 23.1<br>22.5          | 4             | 64     | B 8 x 15       |
| x 200      | 1 057 0070 00<br>1 057 0071 00 | 21.1<br>20.5                                  | 22.1<br>21.5          | 23.1<br>22.5          |               |        |                |

### Assembly tools 9037/11037

Hub nut spanner  
 Brake shoe clamping device  
 Brake drum fixing flanges  
 Wheel bearing inserter  
 Puller for MS bushing  
 Bushing tool for MS bushing

### SAF parts no.

1 012 0024 00  
 3 349 1001 00  
 3 434 1040 01  
 3 434 1059 00  
 1 434 1056 00  
 1 434 1055 00


## Exploded view of SK RS/RZ 9037/11037 axle assembly Torque wrench settings

Use torque wrench.  
The use of impact  
wrenches is not accepted.

**Wheel nuts:**  
Spigot-hub-centred fixing:  
M 22 x 1.5 / 600 Nm  
Bolt-centred fixing:  
M 22 x 1.5 / 430 Nm

**U-bolts:**  
(diagonally in  
three stages)  
M 24 / 700 Nm  
M 22 / 650 Nm  
M 20 / 500 Nm

**Shock absorber:**  
M 24 / 400 Nm



## SK RS/RZ 9037/11037

| Item | Parts designation  | Item | Parts designation  |
|------|--|------|--|
| 01   | <b>Axle beam assembly</b><br>including items 3 - 6, 010, 19,<br>22 - 22.1, 25              | 64   | <b>Brake shoe assembly</b><br>including items 65, 71 - 73          |
| 3    | Spherical mounting plate   | 65   | Brake shoe with item 66  |
| 4    | Protection plug  | 66   | Cam roller   |
| 4.1  | Protection plug (axle tube)  | 70   | <b>Lining service group</b><br>including items 71, 72, 73          |
| 5    | Ball   | 71   | Brake lining, cam roller side                                      |
| 6    | Camshaft bearing, brake carrier side   | 72   | Brake lining, ball side  |
| 6.1  | Riffle bolt  | 73   | Rivet  |
| 6.2  | Hex nut  | 74   | Spring clip  |
| 010  | <b>Camshaft bearing assembly,</b><br>linkage adjustment side<br>including items 12, 15, 18 | 75   | Return spring  |
| 12   | Camshaft bearing   |      | <u>with ABS</u>  |
| 15   | Hex bolt   | 76   | Bracket sensor   |
| 18   | Bellows  | 76.2 | Hex bolt   |
| 18.3 | Brake lining wear gauge  | 78   | ABS sensor   |
| 19   | O-ring - Hub nut   | 081  | <b>Camshaft assembly (LH)</b><br>including items 18.3, 85.1 - 88.1 |
| 20   | O-ring - Stub axle   | 082  | <b>Camshaft assembly (RH)</b><br>including items 18.3, 85.1 - 88.1 |
| 22   | Hub nut, RH thread   | 85.1 | Disc spring  |
| 22.1 | Hub nut, LH thread   | 86   | Spring clip  |
| 25   | Brake cylinder support   | 87   | Washer   |
| 27   | Hub unit, complete<br>with item 27.2   | 88   | Washer   |
| 27.2 | Repair kit including items<br>27.3, 38 - 39  | 88.1 | Spring clip  |
| 27.3 | Bearing grease   |      | <u>with automatic adjustment</u>                                   |
| 29   | Brake drum   | 89.1 | Automatic slack adjuster   |
| 30   | <b>Wheel bolt assembly</b><br>including items 31 - 34                                      | 89.2 | Anchor plate, RH   |
| 31   | Riffle bolt  | 89.3 | Anchor plate, LH   |
| 34   | Wheel nut  | 90   | Return spring  |
| 38   | Inner seal ring  | 091  | <b>Dust cover assembly</b><br>including items 92 - 98, 99          |
| 38.1 | Outer seal ring  | 92   | Dust cover, RH   |
| 39   | O-ring - Hub cap   | 93   | Dust cover, LH   |
| 40   | Hub cap, complete with items 39, 41  | 94   | Plug   |
| 40.1 | Hub cap, complete with pole wheel<br>and items 39 - 41                                     | 95   | Cable clamp  |
| 41   | Plug   | 96   | Hex bolt   |
| 059  | <b>Brake assembly</b><br>including items 64, 74 - 75                                       | 97   | Clamp  |
|      |  | 98   | Plug   |
|      |  | 99   | Rubber grommet, ABS  |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.

## for SAF SK RS/RZ 9030/11030 / RZ 12030 axles and suspension units (steering axle see p. 36-37)

| Service schedule      |                     | Periodic checks         |                 |                 |                  |
|-----------------------|---------------------|-------------------------|-----------------|-----------------|------------------|
|                       |                     | After first 5,000 km or | every 30,000 km | every 90,000 km | every 150,000 km |
| Whichever comes first | Mileage intervals > | after first month       | every 3 months  | every 6 months  | every 12 months  |
|                       | Time intervals >    |                         |                 |                 |                  |

### Mechanical check

|   |   |  |   |   |
|---|---|--|---|---|
| <b>Note:</b><br>Torque check wheel nuts after the first 50 km and 150 km (and after every wheel removal).   |   |  |   |   |
| Torque check all nuts and bolts to recommended setting.   | • |  |   | • |
| Check and adjust hub end-float (if required).<br>Pack wheel bearings with fresh grease after 300,000 km or 36 month, whichever comes first. Check condition of taper roller bearings and replace, if necessary. |   |  | • |   |
| Lubricate camshaft bearings after every brake lining replacement, however, at least every 12 months.  |   |  |   | • |

### Visual inspection for wear/damage

|   |   |   |  |  |
|---|---|---|--|--|
| Check suspension components for wear, fluid leakage and damage<br>Check brake linings for wear<br><b>Check camshafts for free movement</b><br>Check slack adjusters for correct function<br>Check braking system for leaks (brake applied)<br>Check air suspension for air leaks<br>Check air suspension bellows for damage<br>Check piston surface for contamination and clean, if necessary<br>Check parabolic springs for damage, scoring and corrosion<br>Check self steering axle for correct function<br>Check tyre wear and tracking (if required) | • | • |  |  |
|---|---|---|--|--|

### Safety inspection

|  |   |   |  |   |
|--|---|---|--|---|
| Check wheel brakes for correct adjustment<br>Check service brake and hand brake efficiency   | • | • |  |   |
| Check truck-trailer combination for brake compatibility<br>Check service brake pressure to manufacturer's recommendation                                       | • |   |  | • |
| Check air suspension for correct ride height.<br>With 2 levelling valves, the max. permissible bellows pressure difference (LH to RH vehicle side) is 0.2 bar. | • | • |  |   |

### Special service conditions

|   |                                       |
|---|---------------------------------------|
| Vehicles with long standing periods:    | service at specified time intervals   |
| Vehicles used under extreme conditions: | service at suitably reduced intervals |

**Warranty claims will only be accepted as long as the operating and maintenance instructions have been complied with and if SAF approved spare parts have been fitted.**

## for SK RS/RZ 9030 / 11030 / RZ 12030 axles


### Hub end-float setting

Tighten hub nut (22) to a torque of 150 Nm at the same time rotating the hub and drum.  
 Locate the locking collar (23) onto the dowel on the hub nut noting the position of the dowel in relation to the collar. Remove the collar and turn the hub nut 2 1/2 holes anti-clockwise. Reverse the collar and re-locate it onto the repositioned hub nut dowel. Fit the lock nut (24) and tighten using a torque of 400 Nm.  
 Check whether the hub rotates freely and without excessive end-float (adjust if necessary).  
 Replace O-ring (39) and fit the wheel cap.


### Lubricant specification:

Wheel bearings:  
 SAF parts no. 4 387 0011 05  
 Camshaft:  
 SAF parts no. 4 387 0011 05  
 Stub axle:  
 SAF parts no. 4 387 0015 06  
 SAF fitting paste  
 Brake anchor bracket ball:  
 SAF parts no. 4 387 0007 00  
 Copper paste

### Hub nut tightening



After brake relining, lubricate camshaft bearings whilst rotating the camshaft through 360° several times.  
 Do not disassemble the wheel bearing assembly. Use a vacuum cleaner to remove brake dust. Never use pressurised cleaning devices or cleaning fluids on the brake drum and hub. Clean stub axle and apply fresh SAF fitting paste.



### Brake type SNK 300

Max. permissible turned brake drum bore: 373.0 mm  
 Brake drum bore with max. permissible wear: 304.0 mm  
 SAF approved brake linings: BERAL 1541, BREMSKERL 6386  
 Turn new brake linings to brake drum bore dimension + 0.3 mm.  
 When renewing rivets, observe the manufacturer's instructions regarding the brake lining.

| Brake size | SAF parts no, brake lining     | Brake drum/brake lining refacing stages in mm |                       |                       | Brake linings | Rivets | DIN 7338 rivet |
|------------|--------------------------------|---|-----------------------|-----------------------|---------------|--------|----------------|
|            |                                | Nominal size                                  | 1st oversize          | 2nd oversize          |               |        |                |
| SNK 300    |                                | d <sub>0</sub> -300.0                         | d <sub>1</sub> -302.0 | d <sub>2</sub> -303.0 |               |        |                |
| x 150      | 1 057 0034 00<br>1 057 0033 00 | 15.5<br>16.5                                  | 16.7<br>17.7          | 17.1<br>18.1          | 4<br>4        | 64     | B 8 x 15       |
| x 200      | 1 057 0025 00<br>1 057 0024 00 | 15.5<br>16.5                                  | 16.7<br>17.7          | 17.1<br>18.1          | 4<br>4        |        |                |

### Assembly tools

9030 / 11030 / 12030  
 Hub nut spanner  
 Hub puller  
 Wheel bearing/oil seal inserter  
 Mounting drift for wheel bearing  
 Inserter for MS bushing  
 Puller for MS bushing  
 Clamping rings for brake drum clamping flanges

### SAF parts no.

2 012 0023 00  
 3 301 0010 00 or 4 434 3822 00  
 3 434 1014 00  
 3 434 3308 00  
 1 434 1055 00  
 1 434 1056 00  
 3 434 1060 00

## Exploded view of SK RS/RZ 9030/11030 / RZ 12030 axle assembly


### Torque wrench settings

Use torque wrench.  
The use of impact wrenches is not accepted.

**Wheel nuts:**  
Spigot-hub-centred fixing:  
M 22 x 1.5 / 600 Nm  
Bolt-centred fixing:  
M 22 x 1.5 / 430 Nm

**U-bolts:**  
(diagonally in three stages)  
M 24 / 700 Nm  
M 22 / 650 Nm  
M 20 / 500 Nm

**Shock absorber:**  
M 24 / 400 Nm



Production number  
(right/direction of travel)



## SK RS/RZ 9030 / 11030 / RZ 12030

| Item | Parts designation   | Item | Parts designation  |
|------|---|------|--|
| 01   | <b>Axle beam assembly</b><br>including items 3 - 8, 010, 22,        | 70   | <b>Brake lining set</b><br>including items 71, 72, 73            |
| 3    | Spherical mounting plate  | 71   | Brake lining, cam roller side                                    |
| 5    | Ball  | 72   | Brake lining, ball side  |
| 6    | Bearing bush  | 73   | Rivet  |
| 8    | Grease nipple   | 74   | Spring clip  |
| 010  | <b>Camshaft bearing assembly</b><br>including items 11 - 13, 14, 18 | 75   | Return spring  |
| 11   | Spherical bush housing  |      | <u>with ABS</u>  |
| 12   | Spherical bearing bush  | 77   | Exciter  |
| 12.1 | Grease nipple   | 78   | ABS sensor   |
| 13   | O-ring  | 80.1 | Protective hose  |
| 14   | <b>Hex bolt assembly</b><br>including items 15 - 17                 | 80.2 | Clamp  |
| 15   | Hex bolt  | 80.3 | Clamp  |
| 16   | Spring washer   | 081  | <b>Camshaft assembly (RH)</b><br>including items 18.3, 84 - 88.1 |
| 17   | Hex nut   | 082  | <b>Camshaft assembly (LH)</b><br>including items 18.3, 84 - 88.1 |
| 18   | Bellows   | 84   | O-ring   |
| 18.3 | Brake lining wear gauge   | 84.1 | Spacer ring  |
| 22   | Hub nut with dowel  | 85   | Seal ring  |
| 23   | Circlip   | 85.1 | Disc spring  |
| 24   | Locknut   | 86   | Spring clip  |
| 25   | Brake cylinder support  | 87   | Washer   |
| 27   | Hub unit  | 88   | Washer   |
| 29   | Brake drum  | 88.1 | Spring clip  |
| 30   | <b>Wheel bolt assembly</b><br>including items 31 - 34               |      | <u>with automatic adjustment</u>                                 |
| 31   | Riffle bolt   | 89.1 | Automatic slack adjuster   |
| 34   | Wheel nut with pressure plate                                       | 89.2 | Anchor plate, RH   |
| 35   | Tapper roller bearing   | 89.3 | Anchor plate, LH   |
| 36   | Tapper roller bearing   | 90   | Return spring  |
| 37   | Grease seal   | 091  | <b>Dust cover assembly</b><br>including items 92 - 99            |
| 38   | Inner seal ring   | 92   | Dust cover, RH   |
| 38.1 | Protective ring   | 93   | Dust cover, LH   |
| 38.2 | Outer seal ring   | 94   | Plug   |
| 39   | O-ring  | 95   | Cable clamp  |
| 40   | Hub cap,<br>complete with items 39, 41                              | 96   | Hex bolt   |
| 41   | Plug  | 97   | Clamp  |
| 059  | <b>Brake assembly</b><br>including items 64, 74 - 75                | 98   | Plug   |
| 64   | <b>Brake shoe assembly</b><br>including items 65, 71 - 73           | 99   | Rubber grommet, ABS  |
| 65   | Brake shoe with item 66   |      |  |
| 66   | Cam roller  |      |  |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.

## for SAF SK RS/RZ 12242 axles and suspension units (steering axle see p. 30-33)

| Service schedule      |                     | After first 5,000 km or | Periodic checks |                 |                  |
|-----------------------|---------------------|-------------------------|-----------------|-----------------|------------------|
|                       |                     |                         | every 30,000 km | every 90,000 km | every 150,000 km |
| Whichever comes first | Mileage intervals > | after first month       | every 3 months  | every 6 months  | every 12 months  |
|                       | Time intervals >    |                         |                 |                 |                  |

### Mechanical check

| Note:   |   |  |   |   |
|---|---|--|---|---|
| Torque check wheel nuts after the first 50 km and 150 km (and after every wheel removal).   |   |  |   |   |
| Torque check all nuts and bolts to recommended setting.   | • |  |   | • |
| Check and adjust hub end-float (if required).<br>Pack wheel bearings with fresh grease after 300,000 km or 36 month, whichever comes first. Check condition of taper roller bearings and replace, if necessary. |   |  | • |   |
| Lubricate camshaft bearings after every brake lining replacement, however, at least every 12 months.  |   |  |   |   |

### Visual inspection for wear/damage

|   |   |   |  |  |
|---|---|---|--|--|
| Check suspension components for wear, fluid leakage and damage<br>Check brake linings for wear<br><b>Check camshafts for free movement</b><br>Check slack adjusters for correct function<br>Check braking system for leaks (brake applied)<br>Check air suspension for air leaks<br>Check air suspension bellows for damage<br>Check piston surface for contamination and clean, if necessary<br>Check parabolic springs for damage, scoring and corrosion<br>Check self steering axle for correct function<br>Check tyre wear and tracking (if required) | • | • |  |  |
|---|---|---|--|--|

### Safety inspection

|  |   |   |  |   |
|--|---|---|--|---|
| Check wheel brakes for correct adjustment<br>Check service brake and hand brake efficiency   | • | • |  |   |
| Check truck-trailer combination for brake compatibility<br>Check service brake pressure to manufacturer's recommendation                                       | • |   |  | • |
| Check air suspension for correct ride height.<br>With 2 levelling valves, the max. permissible bellows pressure difference (LH to RH vehicle side) is 0.2 bar. | • | • |  |   |

### Special service conditions

|   |                                       |
|---|---------------------------------------|
| Vehicles with long standing periods:    | service at specified time intervals   |
| Vehicles used under extreme conditions: | service at suitably reduced intervals |

**Warranty claims will only be accepted as long as the operating and maintenance instructions have been complied with and if SAF approved spare parts have been fitted.**

## for SK RS/RZ 12242 axles

### Hub end-float setting


Tighten hub nut (22) to a torque of 150 Nm at the same time rotating the hub and drum.

Locate the locking collar (23) onto the dowel on the hub nut noting the position of the dowel in relation to the collar. Remove the collar and turn the hub nut 2 1/2 holes anti-clockwise. Reverse the collar and re-locate it onto the repositioned hub nut dowel. Fit the lock nut (24) and tighten using a torque of 400 Nm.

Check whether the hub rotates freely and without excessive end-float (adjust if necessary).

Replace O-ring (39) and fit the wheel cap.

### Hub nut tightening



After brake relining, lubricate camshaft bearings whilst rotating the camshaft through 360° several times.

Do not disassemble the wheel bearing assembly.

Use a vacuum cleaner to remove brake dust.

Never use pressurised cleaning devices or cleaning fluids on the brake drum and hub.

Clean stub axle and apply fresh SAF fitting paste.

### Lubricant specification:


Wheel bearings:  
SAF parts no. 4 387 0011 05

Camshaft:  
SAF parts no. 4 387 0011 05

Stub axle:  
SAF parts no. 4 387 0015 06  
SAF fitting paste

Brake anchor bracket ball:  
SAF parts no. 4 387 0007 00  
Copper paste

**Never mix different types or grades of grease!**



### Brake type SNK 420

Max. permissible turned brake drum bore:

Brake drum bore with max. permissible wear:

SAF approved brake linings:

Turn new brake linings to brake drum bore dimension + 0.3 mm.

When renewing rivets, observe the manufacturer's instructions regarding the brake lining.

424.0 mm  
425.0 mm  
BERAL 1541, BREMSKERL 6386

| Brake size | SAF parts no. brake lining     | Brake drum/brake lining refacing stages in mm |              |              | Brake linings | Rivets | DIN 7338 rivet |
|------------|--------------------------------|---|--------------|--------------|---------------|--------|----------------|
|            |                                | Nominal size                                  | 1st oversize | 2nd oversize |               |        |                |
| SNK 420    |                                | $d_0$ -420.0                                  | $d_1$ -422.0 | $d_2$ -424.0 |               |        |                |
| x 180      | 1 057 0060 00<br>1 057 0061 00 | 20.6<br>20.0                                  | 21.6<br>21.0 | 22.6<br>22.0 | 4             | 64     | B 8 x 15       |
| x 200      | 1 057 0066 00<br>1 057 0067 00 | 20.6<br>20.0                                  | 21.6<br>21.0 | 22.6<br>22.0 |               |        |                |

### Assembly tools 12242

Hub nut spanner  
Hub puller  
Universal puller for wheel hub  
Bearing inner race  
Wheel bearing/oil seal inserter  
Sealing ring inserter  
Brake shoe clamping device

### SAF parts no.

2 012 0023 00  
3 301 0010 00  
4 434 3822 00  
4 434 3820 00  
3 434 3320 00  
3 434 1036 00  
3 349 1001 00


## Exploded view of SK RS/RZ 12242 axle assembly Torque wrench settings

Use torque wrench.  
The use of impact wrenches is not accepted.

**Wheel nuts:**  
Spigot-hub-centred fixing:  
M 22 x 1.5 / 600 Nm  
Bolt-centred fixing:  
M 22 x 2 / 430 Nm  
M 22 x 1.5 / 430 Nm

**U-bolts:**  
(diagonally in three stages)  
M 24 / 700 Nm  
M 22 / 650 Nm  
M 20 / 500 Nm

**Shock absorber:**  
M 24 / 400 Nm



## SK RS/RZ 12242

| Item | Parts designation  | Item | Parts designation  |
|------|--|------|--|
| 01   | <b>Axle beam assembly</b><br>including items 3, 5,   | 70   | <b>Lining service group</b><br>including items 71, 72, 73          |
| 3    | Spherical mounting plate   | 71   | Brake lining, cam roller side                                      |
| 5    | Ball   | 72   | Brake lining, ball side  |
| 6    | Camshaft bearing, brake carrier side   | 73   | Rivet  |
| 6.1  | Riffle bolt  |      |  |
| 6.2  | Hex nut  | 74   | Spring clip  |
|      |  | 75   | Return spring  |
| 010  | <b>Camshaft bearing assembly,</b><br>linkage adjustment side<br>including items 12, 15, 18 |      | <b>with ABS</b>  |
| 12   | Camshaft bearing   | 77   | Exciter  |
| 15   | Hex bolt   | 78   | ABS sensor   |
| 18   | Bellows  | 80.1 | Protective hose  |
|      |  | 80.2 | Clamp  |
|      |  | 80.3 | Clamp  |
| 18.3 | Brake lining wear gauge  | 081  | <b>Camshaft assembly (RH)</b><br>including items 18.3, 85.1 - 88.1 |
| 22   | Hub nut with dowel   |      |  |
| 23   | Circlip  | 082  | <b>Camshaft assembly (LH)</b><br>including items 18.3, 85.1 - 88.1 |
| 24   | Locknut  | 85.1 | Disc spring  |
| 25   | Brake cylinder support   | 86   | Spring clip  |
| 27   | Hub unit   | 87   | Washer   |
| 29   | Brake drum   | 88   | Washer   |
|      |  | 88.1 | Spring clip  |
| 30   | <b>Wheel bolt assembly</b><br>including items 31 - 34                                      | 89   | Mechanical slack adjuster  |
| 31   | Riffle bolt  |      |  |
| 34   | Wheel nut with pressure plate  |      | <b>with automatic adjustment</b>                                   |
|      |  | 89.1 | Automatic slack adjuster   |
| 35   | Taper roller bearing   | 89.2 | Anchor plate, RH   |
| 36   | Taper roller bearing   | 89.3 | Anchor plate, LH   |
| 37   | Grease seal  |      |  |
| 38   | Inner seal ring  | 90   | Return spring  |
| 38.1 | Protective ring  |      |  |
| 38.2 | Outer seal ring  | 091  | <b>Dust cover assembly</b><br>including items 92 - 99              |
| 39   | O-ring   | 92   | Dust cover, RH   |
| 40   | Hub cap,<br>complete with items 39, 41   | 93   | Dust cover, LH   |
| 41   | Plug   | 94   | Plug   |
| 059  | <b>Brake assembly</b><br>including items 64, 74 - 75                                       | 95   | Cable clamp  |
|      |  | 96   | Hex bolt   |
| 64   | <b>Brake shoe assembly</b><br>including items 65, 71 - 73                                  | 97   | Clamp  |
|      |  | 98   | Plug   |
| 65   | Brake shoe with item 66  |      |  |
| 66   | Cam roller   | 99   | Rubber grommet, ABS  |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.

## for K RS/RZ 14242/16242 axles

| Service schedule      | Mileage intervals > | After first 5,000 km or | Periodic checks |                 |                  |
|-----------------------|---------------------|-------------------------|-----------------|-----------------|------------------|
|                       |                     |                         | every 30,000 km | every 90,000 km | every 150,000 km |
| Whichever comes first | Time intervals >    | after first month       | every 3 months  | every 6 months  | every 12 months  |

### Mechanical check

|  |   |  |   |   |
|--|---|--|---|---|
| <b>Note:</b><br>Torque check wheel nuts after the first 50 km and 150 km (and after every wheel removal).    |   |  |   |   |
| Torque check all nuts and bolts to recommended setting.  | • |  | • |   |
| Check and adjust hub end-float (if required).  |   |  | • |   |
| Lubricate camshaft bearings after every brake lining replacement, however, at least every 12 months.         |   |  |   |   |
| Pack wheel bearings with fresh grease (also after every brake lining replacement, check wheel bearing wear). |   |  |   | • |

### Visual inspection for wear/damage

|   |   |   |  |  |
|---|---|---|--|--|
| Check suspension components for wear, fluid leakage and damage<br>Check brake linings for wear<br><b>Check camshafts for free movement</b><br>Check slack adjusters for correct function<br>Check braking system for leaks (brake applied)<br>Check air suspension for air leaks<br>Check air suspension bellows for damage<br>Check piston surface for contamination and clean, if necessary<br>Check parabolic springs for damage, scoring and corrosion<br>Check self steering axle for correct function<br>Check tyre wear and tracking (if required) | • | • |  |  |
|---|---|---|--|--|

### Safety inspection

|  |   |   |  |   |
|--|---|---|--|---|
| Check wheel brakes for correct adjustment<br>Check service brake and hand brake efficiency   | • | • |  |   |
| Check truck-trailer combination for brake compatibility<br>Check service brake pressure to manufacturer's recommendation                                       | • |   |  | • |
| Check air suspension for correct ride height.<br>With 2 levelling valves, the max. permissible bellows pressure difference (LH to RH vehicle side) is 0.2 bar. | • | • |  |   |

### Special service conditions

Vehicles with long standing periods: service at specified time intervals  
 Vehicles used under extreme conditions: service at suitably reduced intervals

**Warranty claims will only be accepted as long as the operating and maintenance instructions have been complied with and if SAF approved spare parts have been fitted.**

## for K RS/RZ 14242/16242 axles

### Hub end-float setting

Tighten hub nut while at the same time turning the hub until slight resistance is felt.

Now slacken the hub nut by 1/12 of a turn until the next locking position is reached. Secure with split pin.

Insert hub puller and pull hub back against outer bearing.

Pack hub cap thread with grease and refit hub cap.

Check whether the hub rotates freely and without excessive end-float (adjust if necessary).

### Lubricant specification:

Wheel bearings:  
SAF parts no. 4 387 0011 05


Camshaft:  
SAF parts no. 4 387 0011 05

Stub axle:  
SAF parts no. 4 387 0015 06  
SAF fitting paste

Brake anchor bracket ball:  
SAF parts no. 4 387 0007 00  
Copper paste

**Never mix different types or grades of grease!**

### Hub nut tightening




After brake relining, lubricate camshaft bearings whilst rotating the camshaft through 360° several times.

Do not disassemble the wheel bearing assembly. Use a vacuum cleaner to remove brake dust.

Never use pressurised cleaning devices or cleaning fluids on the brake drum and hub.

Clean stub axle and apply fresh SAF fitting paste.



### Brake type SNK 420

Max. permissible turned brake drum bore:

Brake drum bore with max. permissible wear:

SAF approved brake linings:

Turn new brake linings to brake drum bore dimension + 0.3 mm.

When renewing rivets, observe the manufacturer's instructions regarding the brake lining.

424.0 mm  
425.0 mm  
BERAL 1541, BREMSKERL 6386

| Brake size | SAF parts no. brake lining     | Brake drum/brake lining refacing stages in mm |                       |                       | Brake linings | Rivets | DIN 7338 rivet |
|------------|--------------------------------|---|-----------------------|-----------------------|---------------|--------|----------------|
|            |                                | Nominal size                                  | 1st oversize          | 2nd oversize          |               |        |                |
| SNK 420    |                                | d <sub>0</sub> -420.0                         | d <sub>1</sub> -422.0 | d <sub>2</sub> -424.0 |               |        |                |
| x 180      | 1 057 0060 00<br>1 057 0061 00 | 20.6<br>20.0                                  | 21.6<br>21.0          | 22.6<br>22.0          | 4             | 64     | B 8 x 15       |
| x 200      | 1 057 0066 00<br>1 057 0067 00 | 20.6<br>20.0                                  | 21.6<br>21.0          | 22.6<br>22.0          |               |        |                |

### Assembly tools

#### Axle types

Hub nut spanner

Hub puller

Universal puller for wheel hub

Bearing inner race

Wheel bearing/oil seal inserter

Brake shoe clamping device

Puller for MS bushing Ø 46 mm

Bushing tool Ø 50/46 mm and Ø 42/38 mm

#### SAF parts no. 14242

1 012 0011 01

3 301 0006 02

4 434 3822 00

4 434 3815 00

3 434 3300 00

3 349 1001 00

1 434 1056 00

1 434 1055 00

#### 16242

1 012 0013 00

3 301 0007 01

4 434 3822 00

4 434 3816 00

3 434 3301 00

3 349 1001 00

1 434 1056 00

1 434 1055 00


## Exploded view of K RS/RZ 14242/16242 axle assembly Torque wrench settings

Use torque wrench.  
The use of impact  
wrenches is not accepted.

**Wheel nuts:**  
Spigot-hub-centred fixing:  
M 22 x 1.5 / 600 Nm  
Bolt-centred fixing:  
M 22 x 2 / 430 Nm  
M 22 x 1.5 / 430 Nm

**U-bolts:**  
(diagonally in  
three stages)  
M 24/700 Nm  
M 22/650 Nm  
M 20/500 Nm

**Shock absorber:**  
M 24/400 Nm





## K RS/RZ 14242/16242

| Item | Parts designation  | Item | Parts designation  |
|------|--|------|--|
| 01   | <b>Axle beam assembly</b><br>including items 3, 5, 6, 8                                    | 73   | Rivet  |
| 3    | Spherical mounting plate   | 74   | Spring clip  |
| 5    | Ball   | 75   | Return spring  |
| 6    | Bearing bush   |      | <b>with ABS</b>  |
| 8    | Grease nipple  | 77   | Exciter  |
| 010  | <b>Camshaft bearing assembly,</b><br>linkage adjustment side<br>including items 12, 15, 18 | 78   | ABS sensor   |
| 12   | Camshaft bearing   | 80.1 | Protective hose  |
| 15   | Hex bolt   | 80.2 | Clamp  |
| 18   | Bellows  | 80.3 | Clamp  |
| 18.3 | Brake lining wear gauge  | 081  | <b>Camshaft assembly (RH)</b><br>including items 18.3, 84 - 88.1 |
| 21   | Thrust washer  | 082  | <b>Camshaft assembly (LH)</b><br>including items 18.3, 84 - 88.1 |
| 22   | Hub nut  | 84   | O-ring   |
| 23   | Splint pin   | 84.1 | Spacer ring  |
| 25   | Brake cylinder support   | 85   | Seal ring  |
| 27   | Hub unit   | 85.1 | Disc spring  |
| 28   | Grooved pin  | 86   | Spring clip  |
| 29   | Brake drum   | 87   | Washer   |
| 30   | <b>Wheel bolt assembly</b><br>including items 31 - 34                                      | 88   | Washer   |
| 31   | Wheel bolt   | 88.1 | Spring clip  |
| 32   | Hex nut  | 89   | Mechanical slack adjuster  |
| 34   | Wheel nut with pressure plate  |      | <b>with automatic adjustment</b>                                 |
| 35   | Taper roller bearing   | 89.1 | Automatic slack adjuster   |
| 36   | Taper roller bearing   | 89.2 | Anchor plate, RH   |
| 37   | Grease seal  | 89.3 | Anchor plate, LH   |
| 40   | Hub cap  | 90   | Return spring  |
| 059  | <b>Brake assembly</b><br>including items 64, 74 - 75                                       | 091  | <b>Dust cover assembly</b><br>including items 92 - 99            |
| 64   | <b>Brake shoe assembly</b><br>including items 65, 71 - 73                                  | 92   | Dust cover, RH   |
| 65   | Brake shoe with item 66  | 93   | Dust cover, LH   |
| 66   | Cam roller   | 94   | Plug   |
| 70   | <b>Lining service group</b><br>including items 71, 72, 73                                  | 95   | Cable clamp  |
| 71   | Brake lining, cam roller side  | 96   | Hex bolt   |
| 72   | Brake lining, ball side  | 97   | Clamp  |
|      |  | 98   | Plug   |
|      |  | 99   | Rubber grommet, ABS  |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.

## for SAF Disc brakes, axle types SK RS/RZ 9022 K/11222 K (22.5") and 9019 K/11019 K (19.5")

| Service schedule      | Mileage intervals > | after first 5,000 km | Periodic checks |                  |
|-----------------------|---------------------|----------------------|-----------------|------------------|
|                       |                     |                      | every 30,000 km | every 150,000 km |
| Whichever comes first | Time intervals >    | after first month    | every 3 months  | every 12 months  |

### Mechanical check

|  |   |  |   |
|--|---|--|---|
| <b>Note:</b><br>Torque check wheel nuts after the first 50 km and 150 km (and after every wheel removal).  |   |  |   |
| Torque check all nuts and bolts to recommended setting.  | • |  | • |
| Hub end-float adjustment not required.<br>Pack wheel bearings with fresh grease after 500,000 km or 50 months, whichever comes first.<br>Check condition of taper roller bearings and replace, if necessary. |   |  |   |

### Visual inspection for wear / damage

|   |   |   |  |
|---|---|---|--|
| Check suspension components for wear, fluid leakage and damage  |   |   |  |
| Check brake linings for wear<br><b>(Inspect all rubber sealing elements on the brake calliper when replacing brake linings)</b> |   |   |  |
| Check brake system for leaks (operate brakes)   |   |   |  |
| Check air suspension system for leaks   | • | • |  |
| Check air bag for damage  |   |   |  |
| Clean piston surface, if soiled   |   |   |  |
| Check parabolic springs for corrosion and damage  |   |   |  |
| Check self steering axle for correct function   |   |   |  |
| Check tyre wear and track widths, if required   |   |   |  |

### Safety inspection

|  |   |   |   |
|--|---|---|---|
| Check wheel brakes for correct adjustment  | • | • |   |
| Check service brake and hand brake efficiency  |   |   |   |
| Check truck-trailer combination for brake compatibility  |   |   |   |
| Check service brake pressure to manufacturer's recommendation  | • |   | • |
| Check air suspension for correct ride height.<br>With 2 levelling valves, the max. permissible bellows pressure difference (LH to RH vehicle side) is 0.2 bar. | • | • |   |

### Special service conditions

|   |                                       |
|---|---------------------------------------|
| Vehicles with long standing periods:    | service at specified time intervals   |
| Vehicles used under extreme conditions: | service at suitably reduced intervals |

**Warranty claims will only be accepted as long as the operating and maintenance instructions have been complied with and if SAF approved spare parts have been fitted.**

## for SK RS/RZ 9022 K/11222 K (22.5") and 9019 K/11019 K (19.5") axles

### Hub end float setting, lubricant

Hub end float adjustment is not necessary.

Replace wheel bearing grease after 500,000 km or 50 months, whichever comes first.

Check condition of taper roller bearings at grease change and replace, if necessary.

Replace O-ring (39) and fit the wheel cap.

After brake relining, observe the following points:

Inspect the seals on the brake calliper. Do not dismantle the wheel bearing assembly. Never use high-pressure cleaners or cleaning fluids on the brake disc or wheel hub.

Clean stub axle of any old grease and apply fresh SAF fitting paste.

### Lubricant specification:

Wheel bearings:

SAF parts no. 4 387 0011 05

Tappet boots and brass bushes:

SAF parts no. 4 387 0016 00

Rubber guide bush (70.3):


SAF parts no. 4 387 0017 01

Stub axle:

SAF parts no. 4 387 0015 06

SAF fitting paste

### Hub nut tightening




LH direction of travel - LH thread.

RH direction of travel - RH thread.

Pretighten to 150 Nm whilst rotating wheel hub and disc.

For final torque, continue tightening through one more scale line (10°).

Hub nuts with LH threads are marked with a groove milled into the hex outside.



### NOTE!

Failure to observe these instructions may result in an accident risk! Worn brake linings or excessively worn brake discs result in a reduction in the braking efficiency or in a complete failure of the brake system.

| Brake type | Thickness of brake disc "A" | Wear limit of brake disc "B" | Thickness of linings "C" | Lining wear "E" | Disc diameter in mm | No. of brake pads per axle |
|------------|-----------------------------|------------------------------|--------------------------|-----------------|---------------------|----------------------------|
| SB7 22.5"  | 45                          | ≤37                          | 30                       | 11              | 430                 | 4                          |
| SB6 19.5"  | 45                          | ≤37                          | 30                       | 11              | 377                 | 4                          |

| Item No.    |  | Tightening torque (Nm) | Spanner size (W.A.F.) | Hexagon |        |
|-------------|--|------------------------|-----------------------|---------|--------|
|             |  |                        |                       | outside | inside |
| 70.6 + 70.7 | Guide bearing on brake calliper<br>2 hex. socket head screws<br>M16 x 1.5 - 10,9 | 290                    | 14                    | -       | X      |
|             | Diaphragm/combination cylinder<br>2 hex. nuts<br>M16 x 1.5                       | 210                    | 24                    | X       | -      |
|             | Brake calliper mounting<br>on axle body<br>M16 x 1.5 x 55                        | 290                    | 24                    | X       | -      |

### Assembly tools

Hub nut spanner

Puller for wheel hub

Lever for wheel hub

### SAF parts no.

1 012 0024 00

4 434 3822 00

1 434 1041 00


## Exploded view of SK RS/RZ 9022 K/11222 K/9019 K/11019 K Torque wrench settings

Use torque wrench.  
The use of impact  
wrenches is not accepted.

**Wheel nuts:**  
Spigot-hub-centred fixing:  
M 22 x 1.5 / 600 Nm  
Bolt-centred fixing:  
M 22 x 1.5 / 430 Nm

**U-bolts:**  
(diagonally in  
three stages)  
M 22/650 Nm

**Shock absorber:**  
M 24/400 Nm



\* up to February 2002 Knorr  
Disc brake type SB 7...

\*\* from March 2002 Knorr  
Disc brake type SN 7...

## SK RS/RZ 9022 K/11222 K/9019 K/11019 K

| Item | Parts designation               | Item  | Parts designation                               |
|------|---------------------------------|-------|---|
| 01   | <b>Axle beam assembly</b>       | 59/60 | <b>Brake calliper assembly</b>                  |
| 4    | Protective plug ABS             |       | including items 61/62, 65, 66,                  |
| 4.1  | Protective plug axle tube       |       | 70, 81  |
| 19   | O-ring                          | 064   | Brake pad set                                   |
| 20   | O-ring                          |       | including items 63, 64.1, 64.2                  |
| 22   | Axle nut, RH                    | 66    | Tappet with boot                                |
| 22.1 | Axle nut, LH                    |       | including items 66.1 - 66.2                     |
| 27   | <b>Wheel hub unit, complete</b> | 70    | <b>Guide pin group</b>                          |
|      | <b>including item 27.2</b>      |       | including items 70.1 - 70.4                     |
| 27.2 | Wheel bearing repair kit        |       | <b>with ABS</b>                                 |
|      | including items 27.3, 38 - 38.1 |       | Bracket sensor                                  |
| 27.3 | Bearing grease                  | 76    | Hex bolt  |
| 29   | Brake disc                      | 76.2  | ABS sensor                                      |
| 30   | <b>Wheel bolt assembly</b>      | 78    |   |
|      | including items 31 - 34         | 80    | <b>Guide pin group</b>                          |
|      | Bush 1 095 1040 00 not included |       | <b>(folding bellows)</b>                        |
| 31   | Wheel bolt                      |       | including items 80.1 - 80.3, 82                 |
| 34   | Wheel bolt nut                  | 81    | <b>Guide pin group</b>                          |
| 38   | Seal ring                       |       | <b>(steel cap)</b>                              |
| 38.1 | Seal ring                       |       | including items 80.4 - 80.5,                    |
| 39   | O-ring                          |       | 81.1 - 81.2, 83                                 |
| 40   | <b>Wheel cap</b>                |       | <b>This guide pin group 81 should,</b>          |
|      | including items 39, 41          |       | <b>where possible, be used for repairs.</b>     |
| 40.1 | Wheel cap with pole wheel       |       | <b>Important:</b>                               |
| 41   | Plug                            |       | <b>Check the sliding action of the calliper</b> |
| 56   | Hex bolt                        |       | <b>housing for free movement over the</b>       |
| 56.1 | Shoulder bolt                   |       | <b>total range, with pads removed.</b>          |



## Repair kits for SAF disc brakes SK RS/RZ 9022 K/11222 K/9019 K/11019 K

The following repair kits are available:

| Designation                                 | Content (Item No.) |
|---|--------------------|
| AT brake calliper, RH                       | incl. pads         |
| AT brake calliper, LH                       | incl. pads         |
| AT brake calliper, RH                       | without pads       |
| AT brake calliper, LH                       | without pads       |
| Brake calliper carrier with guide kit, RH   | 61, 70, 81         |
| Brake calliper carrier with guide kit, LH   | 62, 70, 81         |
| Guide pin group (folding bellows)           | 80                 |
| Guide pin group (steel cap)                 | 81                 |
| Guide pin group                             | 70                 |
| Tappet with boot                            | 66.1, 66.2         |
| Brake pad retainer kit (per axle)           | 064                |
| Cap for clearance adjuster (4 caps SB 7...) | 65*                |
| Cap for clearance adjuster (4 caps SN 7...) | 65**, 65.1**       |

**All kits available only as complete sets!**

# SAF Trailing steering axles - adjustment



- Adjust dimension "A" to the same length on both sides. Watch toe-in (approx. 4.0 mm).
- Set dimension "B" to a length of 537 mm. The reversing lock must be engaged.
- Check seat of piston rods in stabilizing cylinders, applying stabilizing pressure (min. 2 bar). If there is any play, adjust "C".
- When working on the tracking of the vehicle, stabilising pressure must be applied to the cylinders and the air suspension must be adjusted to the correct height.
- Tighten all bolts to the specified torque, securing nuts with split pins.

## **Attention:**

Make sure there is no load on the axle when lubricating the steering knuckle bearing.

Grease the first time after 1 month, then every 6 months.

LEAD systems have no stabilizing cylinders (530).

Adjustment dimension "B" of the LEAD damper at 537 mm, when engaged in the straight-line position for the trailing steering-axle and the reversing-block.


## Exploded view of SK RLS 9042 / 11242 Torque wrench settings

Use torque wrench.  
The use of impact  
wrenches is not accepted.

**Wheel nuts:**  
Spigot-hub-centred fixing:  
M 22 x 1.5 / 600 Nm  
Bolt-centred fixing:  
M 22 x 1.5 / 430 Nm

**U-bolts:**  
(diagonally in  
three stages)  
M 24 / 700 Nm  
M 22 / 650 Nm

**Shock absorber:**  
M 24 / 400 Nm



For brake and wheel mounting parts,  
refer to the corresponding axle drawing  
(e. g. SK RS/RZ 9042).



## SK RLS 9042 / 11242

| Item | Parts designation  | Item                             | Parts designation   | Item | Parts designation   |  |
|------|--|----------------------------------|---|------|---|--|
| 01   | <b>Axle beam assembly</b><br>including items 1.1 - 1.4   | 82                               | <b>Camshaft assembly (LH)</b><br>including items 18.3,<br>84 - 88.3 | 518  | <b>Bolt kit</b><br>including items<br>519 - 520   |  |
| 1.1  | Mounting bracket LH  | 84                               | O-ring  | 519  | Hex bolt  |  |
| 1.2  | Mounting bracket RH  | 84.1                             | Spacer ring   | 520  | Lock nut  |  |
| 1.3  | Reversing lock, complete   | 86                               | Lock ring   |      |   |  |
| 1.4  | Damper connection  | 87                               | Washer  | 522  | <b>Bolt kit</b><br>including items<br>523, 525  |  |
| 3.1  | <b>Steering knuckle<br/>assembly, LH</b><br>including items 4 - 9,<br>16 - 17, 19 - 20, 22.1, 25,<br>501 - 506 | 88                               | Washer  | 523  | Hex bolt  |  |
|      |  | 88.1                             | Spring clip   | 525  | Lock nut  |  |
|      |  | 88.3                             | Bellows   |      |   |  |
|      |  | <b>with automatic adjustment</b> |   |      |   |  |
|      |  | 89.1                             | Automatic slack adjuster  | 526  | Steering damper   |  |
| 3.2  | <b>Steering knuckle<br/>assembly, RH</b><br>including items 4 - 9,<br>16 - 17, 19 - 20, 22, 25,<br>501 - 506   | 89.2                             | Anchor plate, RH  | 527  | Blocking cylinder   |  |
|      |  | 89.3                             | Anchor plate, LH  | 528  | Cylinder screw  |  |
|      |  | 90                               | Return spring   | 530  | <b>Steering control<br/>differential</b><br>including items<br>531 - 533,<br>534, 538 - 541 |  |
| 4    | Bush   | 501                              | Pivot pin   | 531  | Membrane cylinder   |  |
| 5    | Ball   | 502                              | Pressure plate, top   | 532  | Bevelled washer   |  |
| 6    | Bearing bush   | 503                              | Pressure plate, bottom  | 533  | Push rod  |  |
| 7    | Bearing bush   | 504                              | O-ring  |      |   |  |
| 8    | Hex bolt   | 505                              | Cover plate   | 534  | <b>Yoke assembly</b><br>including items<br>535 - 537  |  |
| 9    | Hex nut  | 505.1                            | Gasket  | 535  | Yoke  |  |
| 16   | Grease nipple  | 506                              | <b>Bolt kit</b><br>including items 507 - 508                        | 536  | Clevis pin  |  |
| 17   | Grease nipple  | 507                              | Hex bolt  | 537  | Split pin   |  |
| 18.3 | Brake lining wear gauge  | 508                              | Spring washer   | 538  | Hex nut   |  |
| 20   | Bearing bush   | 512                              | <b>Tie-rod assembly</b><br>including items<br>513 - 515, 518        | 539  | Bellows   |  |
| 25   | Mounting bracket   | 513                              | Tie-rod tube  | 540  | Clamp   |  |
| 66   | Cam roller   | 514                              | Ball joint, LH  | 541  | Clamp   |  |
|      |  |                                  | Ball joint, RH  |      |   |  |
| 81   | <b>Camshaft assembly (RH)</b><br>including items 18.3,<br>84 - 88.3  | 515                              | Clamp   |      |   |  |
|      |  | 516                              | Clamping plate  |      |   |  |
|      |  | 517                              | Clamping fork   |      |   |  |

**Trailing steering axle with LEAD system. (LEAD = damping effect as a function of steering lock angle).** Steering stabilization is effected via the steering damper, i.e. item 530 (Steering control differential) is no longer required. Adjustment dimension "B" of the LEAD damper at 537 mm, when engaged in the straight-line position for the trailing steering-axle.

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.



## SK RLZ 9037 / 11037

| Item | Parts designation  | Item  | Parts designation  | Item | Parts designation                                    |
|------|--|-------|--|------|--|
| 01   | <b>Axle beam assembly</b><br>including items 1.1 - 1.3   |       | <b>with automatic adjustment</b>   | 534  | <b>Yoke assembly</b><br>including items<br>535 - 537 |
| 1.1  | Mounting bracket LH  | 89.1  | Automatic slack adjuster   |      |  |
| 1.2  | Mounting bracket RH  | 89.2  | Anchor plate, RH   |      |  |
| 1.3  | Reversing lock, complete   | 89.3  | Anchor plate, LH   | 535  | Yoke   |
| 1.4  | Damper connection  |       |  | 536  | Clevis pin   |
|      |  | 90    | Return spring  | 537  | Splint pin   |
| 3.1  | <b>Steering knuckle assembly, LH</b><br>including items 4 - 9,<br>16 - 20, 22.1, 25, 501 - 506 | 501   | Pivot pin  | 538  | Hex nut  |
|      |  | 502   | Pressure plate, top  | 539  | Bellows  |
|      |  | 503   | Pressure plate, bottom   | 540  | Clamp  |
|      |  | 504   | O-ring   | 541  | Clamp  |
| 3.2  | <b>Steering knuckle assembly, RH</b><br>including items 4 - 9,<br>16 - 20, 22, 25, 501 - 506   | 505   | Cover plate  |      |  |
|      |  | 505.1 | Gasket   |      |  |
| 4    | Bush   | 506   | <b>Bolt kit</b><br>including items 507 - 508   |      |  |
| 5    | Ball   | 507   | Hex bolt   |      |  |
| 6    | Bearing bush   | 508   | Spring washer  |      |  |
| 7    | Bearing bush   |       |  |      |  |
| 8    | Hex bolt   | 512   | <b>Tie-rod assembly</b><br>including items 513 - 515,<br>518                         |      |  |
| 9    | Hex nut  |       |  |      |  |
| 16   | Grease nipple  | 513   | Tie-rod tube   |      |  |
| 17   | Grease nipple  | 514   | Ball joint, LH   |      |  |
|      |  |       | Ball joint, RH   |      |  |
| 18.3 | Brake lining wear gauge  | 515   | Clamp  |      |  |
| 25   | Mounting bracket, LH<br>Mounting bracket, RH   | 516   | Clamping plate   |      |  |
| 81   | <b>Camshaft assembly (RH)</b><br>including items 18.3,<br>84 - 88.3                            | 518   | <b>Bolt kit</b><br>including items 519 - 520   |      |  |
|      |  | 519   | Hex bolt   |      |  |
|      |  | 520   | Hex nut  |      |  |
| 82   | <b>Camshaft assembly (LH)</b><br>including items 18.3,<br>84 - 88.3                            | 527   | Blocking cylinder  |      |  |
|      |  | 528   | Cylinder screw   |      |  |
| 84   | O-ring   | 530   | <b>Steering control differential</b><br>including items 531 - 533,<br>534, 538 - 541 |      |  |
| 84.1 | Spacer ring  |       |  |      |  |
| 86   | Circlip  | 531   | Membrane cylinder  |      |  |
| 87   | Washer   | 532   | Bevelled washer  |      |  |
| 88   | Washer   | 533   | Push rod<br>including items 535 - 537  |      |  |
| 88.1 | Spring clip  |       |  |      |  |
| 88.3 | Bellows  |       |  |      |  |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.



## SK RLZ 9030 / 11030

| Item | Parts designation   | Item                                     | Parts designation                            | Item | Parts designation                                    |
|------|---|--|--|------|--|
| 01   | <b>Axle beam assembly</b><br>including items 1.1 - 1.3  | <b>with automatic adjustment</b>         |  | 534  | <b>Yoke assembly</b><br>including items<br>535 - 537 |
| 1.1  | Mounting bracket, LH  | 89.1                                     | Automatic slack adjuster                     |      |  |
| 1.2  | Mounting bracket, RH  | 89.2                                     | Anchor plate, RH                             |      |  |
| 1.3  | Reversing lock, complete  | 89.3                                     | Anchor plate, LH                             | 535  | Yoke   |
| 1.4  | Damper connection   | 90                                       | Return spring                                | 536  | Clevis pin   |
|      |   |  |  | 537  | Splint pin   |
| 3.1  | <b>Steering knuckle assembly LH</b><br>including items 4 - 9,<br>16 - 20, 22.1, 25, 501 - 506 | 501                                      | Pivot pin                                    | 538  | Hex nut  |
|      |   | 502                                      | Pressure plate, top                          | 539  | Bellows  |
|      |   | 503                                      | Pressure plate, bottom                       | 540  | Clamp  |
|      |   | 504                                      | O-ring                                       | 541  | Clamp  |
|      |   | 505                                      | Cover plate                                  |      |  |
| 3.2  | <b>Steering knuckle assembly RH</b><br>including items 4 - 9,<br>16 - 20, 22, 25, 501 - 506   | 505.1                                    | Gasket                                       |      |  |
|      |   | <b>506 Bolt kit</b>                      | including items 507 - 508                    |      |  |
| 4    | Bush  | 507                                      | Hex bolt                                     |      |  |
| 5    | Ball  | 508                                      | Spring washer                                |      |  |
| 6    | Bearing bush  |  |  |      |  |
| 7    | Bearing bush  | <b>512 Tie-rod assembly</b>              | including items                              |      |  |
| 8    | Hex bolt  |  | 513 - 515, 518                               |      |  |
| 9    | Hex nut   |  |  |      |  |
|      |   | 513                                      | Tie-rod tube                                 |      |  |
| 16   | Grease nipple   | 514                                      | Ball joint, LH                               |      |  |
| 17   | Grease nipple   |  | Ball joint, RH                               |      |  |
|      |   | 515                                      | Clamp  |      |  |
| 18.3 | Brake lining wear gauge   |  |  |      |  |
| 25   | Mounting bracket, LH  | 516                                      | Clamping plate                               |      |  |
|      | Mounting bracket, RH  |  |  |      |  |
| 81   | <b>Camshaft assembly (RH)</b><br>including items 18.3,<br>84 - 88.3                           | <b>518 Bolt kit</b>                      | mit Teilen 519 - 520                         |      |  |
|      |   | 519                                      | Hex bolt                                     |      |  |
|      |   | 520                                      | Lock nut                                     |      |  |
| 82   | <b>Camshaft assembly (LH)</b><br>including items 18.3,<br>84 - 88.3                           | 527                                      | Blocking cylinder                            |      |  |
|      |   | 528                                      | Cylinder screw                               |      |  |
| 84   | O-ring  | <b>530 Steering control differential</b> | including items 531 - 533,<br>534, 538 - 541 |      |  |
| 84.1 | Spacer ring   |  |  |      |  |
| 86   | Lock ring   | 531                                      | Membrane cylinder                            |      |  |
| 87   | Washer  | 532                                      | Bevelled washer                              |      |  |
| 88   | Washer  | 533                                      | Push rod                                     |      |  |
| 88.1 | Spring clip   |  |  |      |  |
| 88.3 | Bellows   |  |  |      |  |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.



## Air Suspension Series M

| Item  | Parts designation   | Item  | Parts designation                  |
|-------|---|-------|------------------------------------|
| 1     | <b>Axle assembly</b>  | 222   | Washer                             |
| 100   | <b>Front hanger bracket</b>                                     | 223   | Hex nut                            |
| 104   | Spigot flange   | 228   | Shock absorber                     |
| 200   | <b>Hex bolt assembly</b><br>including items 201, 202            | 230   | Hex bolts                          |
| 201   | Hex bolt M30  | 232.1 | Washer                             |
| 202   | Lock nut M30  | 232.2 | Hex nut                            |
| 207   | U-Profiles  | 232.3 | U-washer                           |
| 208   | Eccentric bush  | 233   | Mounting plate                     |
| 208.1 | Thrust washer   | 234   | Air bellows                        |
| 209   | <b>Trailing arm spring assembly</b><br>including items 211, 214 | 235.1 | Hex bolt                           |
| 210   | Thrust block  | 235.2 | Lock nut                           |
| 211   | Retainer plate  | 236   | Hex bolt                           |
| 214   | Bearing bush HD   | 236.1 | Self-tapping screw                 |
| 219   | Spring seat   | 237   | Spring washer                      |
| 220   | <b>U-bolt kit</b><br>including items 221 - 223                  | 239   | Hex nut                            |
| 221   | U-bolt  | 240   | Mounting plate                     |
|       |   | 240.1 | Air suspension mounting<br>bracket |
|       |   | 242   | Clamping plate                     |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.

## Air Suspension – Series O

### Torque wrench settings

Refer to appropriate axle type maintenance chart for more detailed maintenance instructions.

Maximum adjustment of hanger bracket using eccentric bush (208):  $\pm 6$  mm

#### Tightening directions:

Tighten spring seat and shock absorber fixings at the ride height. Parts are ready to be assembled – the threads must not be oiled or greased!

#### Pivot clamping bolt assembly

Torque – tightening procedure

Pre-tighten to 400 Nm + final tightening torque 120° (see page 44)  
120° rotation (2 flats of the nut)

Shock absorber fixing (232.2):

400 Nm

Air bag hexagon head bolt (steel immersion piston 236):

80 Nm

Air bag self-tapping bolt (plastic immersion piston 236.1):

20 Nm


Air bag mounting bolt (235.2):

180 Nm

Air suspension bag upper (239):

40 Nm

U-bracket, see axle type in question.





## Air Suspension – Series O

| Item  | Parts designation   | Item  | Parts designation                  |
|-------|---|-------|------------------------------------|
| 1     | <b>Axle assembly</b>  | 222   | Washer                             |
| 100   | <b>Front hanger bracket</b>                                     | 223   | Hex nut                            |
| 104   | Spigot flange   | 228   | Shock absorber                     |
| 200   | <b>Hex bolt assembly</b><br>including items 201, 202            | 230   | Hex bolts                          |
| 201   | Hex bolt M30  | 232.1 | Washer                             |
| 202   | Lock nut M30  | 232.2 | Hex nut                            |
| 207   | U-Profiles  | 232.3 | U-washer                           |
| 208   | Eccentric bush  | 233   | Mounting plate                     |
| 208.1 | Thrust washer   | 234   | Air bellows                        |
| 209   | <b>Trailing arm spring assembly</b><br>including items 211, 214 | 235.1 | Hex bolt                           |
| 210   | Thrust block  | 235.2 | Lock nut                           |
| 211   | Retainer plate  | 236   | Hex bolt                           |
| 214   | Bearing bush HD   | 236.1 | Self-tapping screw                 |
| 219   | Spring seat   | 237   | Spring washer                      |
| 220   | <b>U-bolt kit</b><br>including items 221 - 223                  | 239   | Hex nut                            |
| 221   | U-bolt  | 240   | Mounting plate                     |
|       |   | 240.1 | Air suspension mounting<br>bracket |
|       |   | 242   | Clamping plate                     |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.

## Air Suspension – Series U

### Torque wrench settings

Refer to appropriate axle type maintenance chart for more detailed maintenance instructions.

Maximum adjustment of hanger bracket using eccentric bush (208):  $\pm 6$  mm

#### Tightening directions:

Tighten spring seat and shock absorber fixings at the ride height. Parts are ready to be assembled – the threads must not be oiled or greased!

#### Pivot clamping bolt assembly

Torque – tightening procedure

Pre-tighten to 400 Nm + final tightening torque 120° (see page 44)  
120° rotation (2 flats of the nut)

Shock absorber fixing (232.2):

400 Nm

Air bag hexagon head bolt (steel immersion piston 236):

80 Nm

Air bag self-tapping bolt (plastic immersion piston 236.1):

20 Nm


Air bag mounting bolt (235.2):

180 Nm

Air suspension bag upper (239):

40 Nm

U-bracket, see axle type in question.



## Air Suspension – Series U

| Item  | Parts designation   | Item  | Parts designation                  |
|-------|---|-------|------------------------------------|
| 1     | <b>Axle assembly</b>  | 222   | Washer                             |
| 100   | <b>Front hanger bracket</b>                                     | 223   | Hex nut                            |
| 104   | Spigot flange   | 228   | Shock absorber                     |
| 200   | <b>Hex bolt assembly</b><br>including items 201, 202            | 230   | Hex bolts                          |
| 201   | Hex bolt M30  | 232.1 | Washer                             |
| 202   | Lock nut M30  | 232.2 | Hex nut                            |
| 207   | U-Profiles  | 232.3 | U-washer                           |
| 208   | Eccentric bush  | 233   | Mounting plate                     |
| 208.1 | Thrust washer   | 234   | Air bellows                        |
| 209   | <b>Trailing arm spring assembly</b><br>including items 211, 214 | 235.1 | Hex bolt                           |
| 210   | Thrust block  | 235.2 | Lock nut                           |
| 211   | Retainer plate  | 236   | Hex bolt                           |
| 214   | Bearing bush HD   | 236.1 | Self-tapping screw                 |
| 219   | Spring seat   | 237   | Spring washer                      |
| 220   | <b>U-bolt kit</b><br>including items 221 - 223                  | 239   | Hex nut                            |
| 221   | U-bolt  | 240   | Mounting plate                     |
|       |   | 240.1 | Air suspension mounting<br>bracket |
|       |   | 242   | Clamping plate                     |

When ordering spare parts quote correct axle identification serial no., refer to the axle type plate.

## Pivot clamping bolt assembly - tightening instruction

For spring brackets made of steel the bearing screw connections require no maintenance. Further adjustments are not necessary. Torque control setting is equal to 1200 Nm.

For spring brackets made of aluminium the bearing screw connections should be checked i.e. adjusted in 6 months intervals. Torque control setting is equal to 1200 Nm.

### REPAIR

It may be necessary, e.g. during repair work, to undo the pivot clamping bolt assembly. In this case, the following combined torque/angle tightening method must be used for reassembly:


Preparatory steps:

- Carefully clean all mating surfaces of pivot HD bush from oil and grease to prevent damage to rubber joints.
- Assemble pivot clamping bolt assembly as shown in the drawing.
- Adjust ride height according to vehicle manufacturer's specifications.

### AIR SPRING


#### 1. Pretightening torque

Use a torque wrench for pretightening the lock nut to 400 Nm (width across flats: 46).



#### 2. Angle tightening to final torque

Continue turning nut through 120° (two flats). Correctly following this procedure means no further tightening will be necessary.



Use an impact wrench or extend lever to L = 2.5 m

Apply marking and inspect visually

## Air suspension - adjusting the ride height


Adjust ride height according to vehicle manufacturer's specifications.

Changes are not permissible because they can lead to damage to axle components.

The ride height is the distance between the axle beam centre and the lower frame edge.

Set the angle (2) between the valve lever (1) and link rod (3) so that the valve lever does not reverse at maximum air bellows extension.

Adjust the ride height using the setting screw (4).



**NOTE:**

Park vehicle on a flat surface.

Release hand brake.

Do not use wedges to keep the axle assembly in position for ride height adjustment

Fill compressed air system to cut-off pressure.

**NOTE:**


In the case of air suspensions with two valves for individual control on either vehicle side, it is essential that both sides are adjusted to the same ride height.

Use two manometers for this purpose. The difference in pressure between the LH and RH bellows must not exceed 0.2 bar.

## Braking system - checking and adjustment


### S-cam brakes with manual slack adjusters

Due to normal brake drum and brake lining wear, the wheel brakes must be regularly adjusted in order to maintain the full brake cylinder stroke. To ensure maximum brake efficiency, the clearance between brake lining and drum must be kept to an absolute minimum. To determine this clearance, check the brake cylinder stroke while full pressure is applied to the service brake. If the path at the yoke end measures more than 2/3 of the maximum cylinder stroke then the brake must be adjusted without delay. With a correctly adjusted brake, it should be impossible to move the piston rod by hand more than 15 mm.




No-load - absolutely no play is permissible between the piston and membrane.


Adjusting screw  
(width across flats 19 mm)




1 Turn adjusting screw to the right until...




2 ... the brake shoes fit closely to the brake drum.



3 Turn adjusting screw to the left, until ...



4 ...the no-load stroke at the slack adjuster (at 127 mm) is approx. 10 - 15 mm long.



5 The wheel must rotate freely with no grating noise.

Special instructions for automatic slack adjusters are given on the following pages.

A = At 1/2 stroke, the angle must not exceed 90°.

B = On full brake application, the slack adjuster and axle beam must not come in contact with each other.

L = Inspect piston rod according to technical specification.

## Automatic slack adjuster Type HALDEX




When interchanging from a manual to an automatic slack adjuster, make sure that you fit replacement adjuster in accordance with type approval by SAF for your specific axle type.

Changes to the adjuster arm length are not permissible.

**NOTE: The installation of an incorrect type of automatic slack adjuster will result in critical effect of serious overheating the brakes.**

References regarding automatic slack adjuster to SAF axles types are available from your SAF service partner at request (see back cover).

## Automatic slack adjuster - adjustment Type HALDEX



- Set cams and brake shoes to released position.
- Observe the correct push rod length "L" as indicated in the SAF specifications.
- **Membrane brake chamber**  
Before installing the automatic slack adjuster, ensure that the brake chamber push rod is in released position.
- By contrast, **spring brake chambers** must be under full operating pressure (min. 6 bar).

**IMPORTANT: If this is not maintained properly, the basic setting will be wrong, with critical effect of overheating the brakes.**

- Grease the camshaft.
- Install anchor bracket (3), being sure to use two fixing bolts (4), do not yet tighten the bolts.
- Install the slack adjuster on the camshaft.
- The arrow (7) points in the braking direction.

- Turn adjusting screw (1) until the bore in the slack adjuster (8.1) coincides with the bore in the clevis end (9) (see drawing).
- Grease split pin (8) and secure.
- Install return spring (10).
- Move the control arm (2) in the direction of the arrow (operating direction of slack adjuster) up to its end position "A" **without** applying excessive force.
- When control arm (2) is in its end position "A", tighten the fixing bolts (4).

- For the anchor bracket mounting (11), ensure that the 2 U-profiles engage firmly together.
- Fit slack adjuster retaining clip on camshaft.
- Axial clearance: Adjust 0.5 - 2 mm using shims.
- Adjust running clearance between brake lining and drum by turning adjusting screw (1) in clockwise direction until the lining fits smoothly against the drum. Then back off adjusting screw (1) by 3/4 turn.



**Do not use impact wrenches!**

### FUNCTION CHECK

- If the self adjuster is functioning correctly, then a minimum torque of 18 Nm must be felt and a grating noise must be heard when adjusting screw (1) is backed off.
- Operate the footbrake several times. Check whether the brake drum rotates freely, check the lining clearance and repeat adjustment procedure if necessary.



## Automatic slack adjuster - adjustment Type S-ABA



- Set cams and brake shoes to released position.
- Observe the correct push rod length "L" as indicated in the SAF specifications.
- **Membrane brake chamber**  
Before installing the automatic slack adjuster, ensure that the brake chamber push rod is in released position.

- By contrast, **spring brake chambers** must be under full operating pressure (min. 6 bar).

**IMPORTANT: If this is not maintained properly, the basic setting will be wrong, with critical effect of overheating the brakes.**

- Grease the camshaft.
- Install anchor bracket (3), being sure to use two fixing bolts (4), do not yet tighten the bolts.
- Install the slack adjuster on the camshaft.
- The arrow (7) points in the braking direction.
- Turn adjusting screw (1) until the bore in the slack adjuster (8.1) coincides with the bore in the clevis end (9) (see drawing).
- For the fixed point mounting, ensure that the 2 U-profiles engage firmly inside one another.
- Grease split pin (8) and secure.
- Install return spring (10).

- Mount slack adjuster on camshaft.
- Axial clearance: Adjust 0.5 - 2 mm using shims.
- Adjust control arm.
- Possible adjustment range for control lever position (slack adjuster) up to its end position **without** applying excessive force.




- Adjust running clearance between brake lining and drum by turning adjusting screw (1) in clockwise direction until the lining fits smoothly against the drum. Then back off adjusting screw (1) by 3/4 turn.

**Do not use impact wrenches!**

#### FUNCTION CHECK

- If the self adjuster is functioning correctly, then a minimum torque of 18 Nm must be felt and a grating noise must be heard when adjusting screw (1) is backed off.
- Operate the footbrake several times. Check whether the brake drum rotates freely, check the lining clearance and repeat adjustment procedure if necessary.

For axle alignment, the air suspension ride height must be adjusted to the values specified by SAF.



Semi-trailers with trailing steering axle


Distance A, B, C max. permissible deviation 1.0 mm

Toe setting  $\pm 12'$  =  $\pm 3.0$  mm/m      Camber  $\pm 12'$

(values apply to unloaded vehicle)

In the case of self steering axles the stabilizing chambers must be pressurised to 2.0 bar.

Total toe-in 4.0 mm/m.



Trailer

Distance A, B, C max. permissible deviation 1.0 mm

Toe setting  $\pm 12'$  =  $\pm 3.0$  mm/m      Camber  $\pm 12'$

(values apply to unloaded vehicle).


The max. permissible deviation values for axle alignment are according to the tyre manufacture specifications.

To avoid excessive tyre wear we recommend having the alignment checked at regular intervals.


Deviations may be caused by:

- loose U-bolts
- spring guide bearing wear
- deformation of axle assembly components due to improper use


The relevant reference point for alignment is the hub cap centre or stub axle centre.




**A Axle types K 14242 / 16242**  
 Tighten hub nut while at the same time turning the hub until slight resistance is felt.  
 Now slacken the hub nut by 1/12 of a turn until the next locking position is reached.  
 Secure with split pin.  
 Using hub puller, pull hub back against outer bearing.  
 Check whether the hub rotates freely and without excessive end-float (adjust if necessary).  
 Pack hub cap thread with grease and refit hub cap, tightening it to 400 Nm.



**B Axle type SK 12242**  
 Tighten hub nut to a torque of 150 Nm at the same time rotating the hub and drum.  
 Locate the locking collar onto the dowel on the hub nut noting the position of the dowel in relation to the collar. Remove the collar and turn the hub nut 2 1/2 holes anti-clockwise.  
 Reverse the collar and re-locate it onto the repositioned hub nut dowel. Fit the lock nut and tighten using a torque of 400 Nm.  
 Check whether the hub rotates freely and without excessive end-float (adjust if necessary).  
 Replace gasket and fit hub cap.



**C Axle types SK 9042, SK 9037, SK 9022 K, 11222 K, 9019 K, 11019 K**  
 Hub end-float adjustment is not required.  
 Tighten hub nut (140 wrench) in the LH direction of travel - LH thread;  
 RH direction of travel - RH thread.  
 Pretighten to 150 Nm whilst rotating drum.  
 For final torque, continue tightening through one more 10° dividing line.




**D Axle types SK 9030 / 11030**  
 Tighten hub nut to a torque of 150 Nm at the same time rotating the hub and drum.  
 Locate the locking collar onto the dowel on the hub nut noting the position of the dowel in relation to the collar. Remove the collar and turn the hub nut 2 1/2 holes anti-clockwise.  
 Reverse the collar and re-locate it onto the repositioned hub nut dowel. Fit the lock nut and tighten using a torque of 400 Nm.  
 Check whether the hub rotates freely and without excessive end-float (adjust if necessary).

# SAF Torque wrench settings

The following tightening torques are only valid if no other values are given in the axle maintenance chart.

Torque wrenches settings, impact wrench not permissible.

| Thread     |  W.A.F. | Material |      |      |
|------------|--|----------|------|------|
|            |  | 8,8      | 10,9 | 12,9 |
| M 8        | W.A.F. 13  | 25       | 35   | 41   |
| M 8 x 1    |  | 27       | 38   | 45   |
| M 10       | W.A.F. 17 / 16   | 49       | 69   | 83   |
| M 10 x 1   |  | 52       | 73   | 88   |
| M 12       | W.A.F. 19 / 18   | 86       | 120  | 145  |
| M 12 x 15  |  | 90       | 125  | 150  |
| M 14       | W.A.F. 22 / 21   | 135      | 190  | 230  |
| M 14 x 1,5 |  | 150      | 210  | 250  |
| M 16       | W.A.F. 24  | 210      | 300  | 355  |
| M 16 x 1,5 |  | 225      | 315  | 380  |
| M 18       | W.A.F. 27  | 300      | 405  | 485  |
| M 18 x 1,5 |  | 325      | 460  | 550  |
| M 20       | W.A.F. 30  | 410      | 580  | 690  |
| M 20 x 1,5 |  | 460      | 640  | 770  |
| M 22       | W.A.F. 32  | 550      | 780  | 930  |
| M 22 x 1,5 |  | 610      | 860  | 1050 |
| M 24       | W.A.F. 36  | 710      | 1000 | 1200 |
| M 24 x 2   |  | 780      | 1100 | 1300 |
| M 27       | W.A.F. 41  | 1050     | 1500 | 1800 |
| M 27 x 2   |  | 1150     | 1600 | 1950 |
| M 30       | W.A.F. 46  | 1450     | 2000 | 2400 |
| M 30 x 2   |  | 1600     | 2250 | 2700 |
| M 36 x 2   | W.A.F. 55  | 2450     | 3450 | 4150 |

### Wheel fixing:

Wheels see appropriate axle maintenance chart.

|               |      |              |
|---------------|------|--------------|
| TRILEX wheels | M 18 | 270 - 300 Nm |
|               | M 20 | 320 - 350 Nm |





**SAF**  
**Vertretungen / Agents / Concessionnaires**  
**Service-Stationen / Service Stations / Points**  
**Service**

|                           |   |  |
|---------------------------|---|--|
| Australia                 | HDTE-Heavy Duty Transport Equipment Pty. Ltd. | (00 61) 3 - 93 69 08 56                                      |
| Austria                   | SAF Hering-Rad Ges.m.b.H.                     | (00 43) 22 36 - 64 65 00                                     |
| Belarus                   | SAF Representative Office                     | (00 375) 17 - 284 90 92                                      |
| Belgium                   | SAF Benelux B.V.                              | (00 31) (0) 3 42 - 49 78 89                                  |
| Bulgaria                  | SAF Trade Bulgarien OOD                       | (00 359) 58 - 2 24 91  |
| Chile                     | Union Tecnica Automotriz S.A.C.               | (00 56) 2 - 6 23 48 51                                       |
| Czech Republic            | SAF Trade, spol. s.r.o.                       | (00 420) 6 32 - 55 71 88                                     |
| Denmark                   | Transport-Komponenter A/S                     | (00 45) 75 52 00 80  |
| Egypt                     | Egyptian Co. for Trading & Construction       | (00 20) 2 - 2 15 23 09                                       |
| Finland                   | Oy Arne Stara AB                              | (00 358) 67 81 87 50   |
| France                    | SAF France S.A.                               | (00 33) 1 - 30 88 09 00                                      |
| Germany                   | Otto Sauer Achsenfabrik Keilberg KG           | (00 49) 0 60 95 - 3 01 - 0                                   |
| Great Britain             | I.M.S. Ltd.                                   | (00 44) 15 09 - 60 01 85                                     |
| Hungary                   | L.V. Technik Kft.                             | (00 36) 76 - 49 35 07  |
| Iceland                   | Stilling                                      | (00 354) 5 - 88 97 97  |
| Israel                    | M.N. Systems Ltd.                             | (00 972) 9 - 8 62 60 30                                      |
| Italy                     | SAF Italia S.r.l.                             | (00 39) 0 45 - 8 25 05 60                                    |
| Malaysia                  | Quality Trailer Components                    | (00 60) 3 - 61 85 82 92                                      |
| Netherlands               | SAF Benelux B.V.                              | (00 31) (0) 3 42 - 49 78 89                                  |
| New Zealand               | Transpecs Ltd.                                | (00 64) 9 - 9 80 73 00                                       |
| Norway                    | MoRek a.s.                                    | (00 47) 67 06 35 00  |
| Peoples Republic of China | Jinan SAF Axle Co. Ltd.                       | (00 86) 5 31 - 8 87 33 61-889                                |
| Poland                    | SAF POLSKA Sp.z.o.o.                          | (00 48) 6 72 16 65 60/70                                     |
| Portugal                  | Suspartes Lda.                                | (00 351) 21 - 2 13 47 10                                     |
| Romania                   | S.C. SAF TRADE RO S.R.L.                      | (00 40) 68 - 25 88 30  |
| Russia                    | SAF-INTCOM                                    | (00 7) 0 95 - 5 79 94 00                                     |
| Republic of Slovakia      | SAF Trade spol s.r.o.                         | (00 421) 38 - 7 60 18 34                                     |
| Slovenia                  | Otto Sauer Achsenfabrik Keilberg KG           | (00 386) 530 - 2 92 13                                       |
| Spain                     | SAF Otto Sauer Achsenfabrik Espana S.L.       | (00 34) 93 - 8 46 81 11                                      |
| Sweden                    | Trailax AB                                    | (00 46) 36 - 16 97 00  |
| Switzerland               | Willy Emy AG                                  | (00 41) 52 - 3 37 21 21                                      |
| Turkey                    | INTERMOBIL A.S.                               | (00 90) 2 12 - 2 85 43 64/65<br>(00 90) 2 12 - 2 86 26 90/91 |
| Yugoslavia                | SAF Representative Office                     | (00 381) 13 52 04 27   |