

FLASHLIGHT INSTRUCTION MANUAL

Manufacturer: Ningbo Sun-Alps Industry Develop Co.,Ltd.

MODEL: LNY09A RATING: 120V, 0.7W

IMPORTANT SAFETY INSTRUCTIONS

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

WARNING: When using, the following basic precautions should always be followed:

- a. Read all the instructions before using the appliance.
- b. To reduce the risk of injury, close supervision is necessary when an appliance is used near children.
- c. Household use **only**. Do not use outdoors.
- d. For a portable appliance To reduce the risk of electric shock, do not put the flashlight in water or other liquid. Do not place or store appliance where it can fall or be pulled into a tub or sink.



INSTALLATION INSTRUCTIONS

To reduce the risk of electric shock, this appliance has a polarized plug (one blade wider than the other). This plug will fit in a polarized outlet **only** one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

OPERATING INSTRUCTIONS

For household use only.

Initial charging time: at least 12h

Normal charging time: 6h

USE-MAINTENANCE INSTRUCTIONS

To reduce the risk of electric shock, unplug before cleaning or servicing.

SAVE THESE INSTRUCTONS