



## PARTS CATALOGUE

### HOFFMANN HIGH PRESSURE WASHERS



<p><b>\$006</b></p>  <p><b>HP120-1512C HP Relay Base</b></p>	<p><b>\$007</b></p>  <p><b>HP118-1512C HP Timer</b></p>	<p><b>\$008</b></p>  <p><b>HPE-2200/RCD Residual Current Device for 3 KW Motor</b></p>	<p><b>\$010</b></p>  <p><b>HP121-1512C HP Timer Base</b></p>
<p><b>\$011</b></p>  <p><b>HP119-1512C HP Relay</b></p>	<p><b>\$012</b></p>  <p><b>HPE-3000/RCD Residual Current Device - 5.5 Kw</b></p>	<p><b>\$013</b></p>  <p><b>Frame Handle Spring HPE-3000-H/Spr</b></p>	<p><b>\$014</b></p>  <p><b>HP105-SP42 Hour Meter</b></p>
<p><b>\$015</b></p>  <p><b>HP-SP05-SSP14 Plastic Single Nozzle for Hand Sprayer</b></p>	<p><b>\$016</b></p>  <p><b>HP-SK10-SSP18 Brass Single Nozzle for Hand Sprayer</b></p>	<p><b>\$021</b></p>  <p><b>HP-SK10-Seal KT Seal for Hand Pump</b></p>	<p><b>\$022</b></p>  <p><b>HP103-SP43 Transparent Cup Water Inlet Filter</b></p>
<p><b>\$023</b></p>  <p><b>HP-SK10-SSP16 Plastic Double Nozzle</b></p>	<p><b>\$024</b></p>  <p><b>HP-SK10-Hose Reinforced Hose Set for SK10</b></p>	<p><b>\$025</b></p>  <p><b>HP-Tube/10 Inner Tube 10" Wheel</b></p>	

<p><b>\$026</b></p>  <p><b>HP-Mounting Mounting Bellow Frame</b></p>	<p><b>\$027</b></p>  <p><b>HP-SG/5000 Short Gun Fits 5000 PSI</b></p>	<p><b>\$029</b></p>  <p><b>HP-Axel/Clipon Axel to Fit Electrical Start Unit</b></p>	<p><b>\$030</b></p>  <p><b>HP-Axel/Bolt Axle to Fit 10" Wheel</b></p>
<p><b>\$031</b></p>  <p><b>HP-Axel/Bolt 14 Axle to Fit 14" Wheel</b></p>	<p><b>\$034</b></p>  <p><b>HP-PSP14/Gun Grip Type Cleaning Gun</b></p>	<p><b>\$042</b></p>  <p><b>HP-NT30/White Nozzle No. 30/2700A</b></p>	<p><b>\$043</b></p>  <p><b>HP-NT30/Red Nozzle Tip No. 30 Fit-2700A</b></p>
<p><b>\$044</b></p>  <p><b>HP-NT30/2700A Nozzle Tips N30 Set of Five</b></p>	<p><b>\$046</b></p>  <p><b>HP-NT35/3200A Nozzle Tips Set of Five</b></p>	<p><b>\$051</b></p>  <p><b>HP-NT40/Black Nozzle Tip No. 40</b></p>	<p><b>\$055</b></p>  <p><b>HP-NT40/Red Nozzle Tip No. 40 Fits 3600A</b></p>
<p><b>\$056</b></p>  <p><b>Nozzle Tips N40 Set of 5 HP-NT40/3600A</b></p>	<p><b>\$058</b></p>	<p><b>\$060</b></p> <p><b>HP-N030/TURBO Turbo Nozzles 030</b></p>	<p><b>\$061</b></p>  <p><b>HP115-1507A Turbo Nozzle Inlet Filter - 1/4" Male Each</b></p>

<p><b>\$062</b></p>  <p><b>HP-N045/Turbo Turbo Nozzle 45</b></p>	<p><b>\$063</b></p>  <p><b>HP-N040/Turbo Turbo Nozzle</b></p>	<p><b>\$064</b></p>  <p><b>HP-Lance/28 Bent Lance Assembly Adjusting Lance 28"</b></p>	<p><b>\$065</b></p>  <p><b>HP-SG/3600 Short Gun Fits 3600 PSI</b></p>
<p><b>\$067</b></p> <p><b>HPE-2200-FAN To fit HPE-2200c-1 Phase</b></p>	<p><b>\$068</b></p> <p><b>HPE-3000-FAN To fit HPE-3000-3 Phase 380V</b></p>	<p><b>\$075</b></p>  <p><b>HP-22WD-001 Crankcase</b></p>	<p><b>\$076</b></p>  <p><b>Oil Inlet Cover HP-22WD-002</b></p>
<p><b>\$077</b></p>  <p><b>HP-22WD-004 Plunger</b></p>	<p><b>\$078</b></p>  <p><b>Plunger Pin HP-22WD-005</b></p>	<p><b>\$079</b></p>  <p><b>HP-22WD-006 Conrod</b></p>	<p><b>\$080</b></p>  <p><b>HP-22WD-010 Crankcase Cover</b></p>
<p><b>\$081</b></p>  <p><b>HP-22WD-011 'O' Ring</b></p>	<p><b>\$082</b></p>  <p><b>HP-22WD-013 Oil Gauge</b></p>	<p><b>\$083</b></p>  <p><b>Drain Plug HP-22WD-014</b></p>	<p><b>\$084</b></p>  <p><b>HP-22WD-016 Crankshaft</b></p>

<p><b>\$085</b></p>  <p><b>HP-22WD-017 6204 2RS-BRG</b></p>	<p><b>\$086</b></p>  <p><b>HP-22WD-018 Ball Bearing Case</b></p>	<p><b>\$087</b></p>  <p><b>HP-22WD-019 Crankshaft Oil Seal</b></p>	<p><b>\$088</b></p>  <p><b>Gasket Washer HP-22WD-020</b></p>
<p><b>\$089</b></p>  <p><b>HP-22WD-022 Crankshaft Cover</b></p>	<p><b>\$090</b></p>  <p><b>HP-22WD-025 Dust Cover</b></p>	<p><b>\$092</b></p>  <p><b>HP-22WD-027 Checking 'O' Ring</b></p>	<p><b>\$094</b></p>  <p><b>HP-22WD-029 Grease Seal</b></p>
<p><b>\$096</b></p>  <p><b>HP-22WD-031 V-Packing Rubber Seal</b></p>	<p><b>\$097</b></p>  <p><b>HP-22WD-032 V-Packing Seat</b></p>	<p><b>\$098</b></p>  <p><b>HP-22WD-033 Set Clip</b></p>	<p><b>\$099</b></p>  <p><b>HP-22WD-037 Cylinder</b></p>
<p><b>\$100</b></p>  <p><b>HP-22WD-038 Grease Cup</b></p>	<p><b>\$101</b></p>  <p><b>Grease Ring HP-22WD-039</b></p>	<p><b>\$102</b></p>  <p><b>HP-22WD-045 Suction Chamber</b></p>	<p><b>\$104</b></p>  <p><b>HP-22WD-050 Water Outlet Chamber</b></p>

<p><b>\$106</b></p>  <p><b>HP-22WD-054 Air Chamber</b></p>	<p><b>\$107</b></p>  <p><b>HP-22WD-055 Pressure Gauge</b></p>	<p><b>\$108</b></p>  <p><b>Cock Valve (Fits All) HP-22WD-056</b></p>	<p><b>\$109</b></p>  <p><b>Outlet Plunger HP-22WD-057</b></p>
<p><b>\$110</b></p>  <p><b>HP-22WD-058 Pressure Adjusting Screw C/W Flynut</b></p>	<p><b>\$111</b></p>  <p><b>Spring Box Chrome HP-22WD-060</b></p>	<p><b>\$112</b></p>  <p><b>Pressure Adjuster HP-22WD-065</b></p>	<p><b>\$113</b></p>  <p><b>HP-22WD-068 Pin</b></p>
<p><b>\$114</b></p>  <p><b>Upper Metal HP-22WD-071</b></p>	<p><b>\$115</b></p>  <p><b>Regulation Ring HP-22WD-072</b></p>	<p><b>\$116</b></p>  <p><b>Spring Seat HP-22WD-073</b></p>	<p><b>\$117</b></p>  <p><b>Spindle Packing HP-22WD-075</b></p>
<p><b>\$119</b></p>  <p><b>HP-22WD-077 Spindle</b></p>	<p><b>\$120</b></p>  <p><b>HP-22WD-078 Spindle Cap</b></p>	<p><b>\$121</b></p>  <p><b>HP-22WD-080 Overflow Seat</b></p>	<p><b>\$122</b></p>  <p><b>Overflow Valve Seat HP-22WD-081</b></p>

<b>\$124</b>	<b>\$125</b>	<b>\$126</b>	<b>\$127</b>
			
HP-22WD-085 V-Pulley	Key HP-22WD-086	Wing Nut HP-22WD-091	Male Joint HP-22WD-092
<b>\$128</b>	<b>\$129</b>	<b>\$130</b>	<b>\$131</b>
			
HP-22WD-093 Suction Packing	HP-22WD-095 Suction Strainer Assembly	HP-22WD-097 Wing Nut	HP-22WD-098 Male Joint
<b>\$133</b>	<b>\$134</b>	<b>\$136</b>	<b>\$137</b>
			
HP-22WD-100 Crankcase Base Set	HP-22WD-103 Adjust Handle	Valve Assembly HP-22WD-444	HP-22WD-58-80 Unloader Assembly
<b>\$138</b>	<b>\$139</b>	<b>\$140</b>	<b>\$141</b>
			
HP-22WD-6-9 Conrod	HP-30WD-001 Crankcase	HP-30WD-002 Oil Inlet Cover	Plunger HP-30WD-004

<b>\$142</b>	<b>\$144</b>	<b>\$147</b>	<b>\$149</b>
			
<b>HP-30WD-005 Plunger Pin</b>	<b>HP-30WD-010 Crankcase Cover</b>	<b>HP-30WD-014 Drain Plug</b>	<b>HP-30WD-017 Bearing</b>
<b>\$150</b>	<b>\$152</b>	<b>\$153</b>	<b>\$154</b>
			
<b>HP-30WD-018 Ball Bearing Case</b>	<b>HP-30WD-020 Ball Bearing Case Gasket</b>	<b>HP-30WD-013 Oil Gauge</b>	<b>HP-30WD-016 Crankshaft</b>
<b>\$156</b>	<b>\$157</b>	<b>\$160</b>	<b>\$164</b>
			
<b>HP-30WD-022 Crankshaft Cover</b>	<b>HP-30WD-025 Dust Proof Cover</b>	<b>HP-30WD-028 Adjusting Ring</b>	<b>HP-30WD-033 Set Clip</b>
<b>\$167</b>	<b>\$168</b>	<b>\$171</b>	<b>\$174</b>
			
<b>HP-30WD-038 Grease Cup</b>	<b>Valve Assembly HP-30WD-039</b>	<b>HP-30WD-051 Stud 10X71</b>	<b>HP-30WD-056 Cock-Valve</b>



<p style="text-align: center;"><b>\$175</b></p>  <p style="text-align: center;"><b>HP-300WD-057 Outlet Plug</b></p>	<p style="text-align: center;"><b>\$178</b></p>  <p style="text-align: center;"><b>HP-30WD-037 Cylinder</b></p>	<p style="text-align: center;"><b>\$179</b></p>  <p style="text-align: center;"><b>HP-30WD-045 Suction Chamber</b></p>	<p style="text-align: center;"><b>\$180</b></p>  <p style="text-align: center;"><b>HP-30WD-050 Water Outlet Chamber</b></p>
<p style="text-align: center;"><b>\$181</b></p>  <p style="text-align: center;"><b>HP-30WD-085 V-Wheel</b></p>	<p style="text-align: center;"><b>\$182</b></p>  <p style="text-align: center;"><b>HP-30WD-095 Suction Strainer Assembly</b></p>	<p style="text-align: center;"><b>\$185</b></p>  <p style="text-align: center;"><b>HP-30WD-086 Keyway</b></p>	<p style="text-align: center;"><b>\$189</b></p>  <p style="text-align: center;"><b>HP-30WD-092 Male Joint</b></p>
<p style="text-align: center;"><b>\$190</b></p>  <p style="text-align: center;"><b>HP-30WD-093 Nylon Washer</b></p>	<p style="text-align: center;"><b>\$191</b></p>  <p style="text-align: center;"><b>HP-30WD-097 Wing Nut</b></p>	<p style="text-align: center;"><b>\$192</b></p>  <p style="text-align: center;"><b>HP-30WD-098 Male Joint</b></p>	<p style="text-align: center;"><b>\$193</b></p>  <p style="text-align: center;"><b>HP-30WD-58-83 Unloader Assembly</b></p>
<p style="text-align: center;"><b>\$194</b></p>  <p style="text-align: center;"><b>HP-30WD-100 Crankcase Base Set of 2</b></p>	<p style="text-align: center;"><b>\$196</b></p>  <p style="text-align: center;"><b>HP-30WD-030 Grease Ring</b></p>	<p style="text-align: center;"><b>\$199</b></p>  <p style="text-align: center;"><b>HP02-1507A Oil Gauge Fits All</b></p>	<p style="text-align: center;"><b>\$200</b></p>  <p style="text-align: center;"><b>HP02/3-1507A Oil Gauge C/W Gasket</b></p>

<p style="text-align: center;"><b>\$203</b></p>  <p style="text-align: center;"><b>HP05-1507A Oil Drain Plug (fits all)</b></p>	<p style="text-align: center;"><b>\$205</b></p>  <p style="text-align: center;"><b>HP09-1507A Oil Inlet Plug (Fits All)</b></p>	<p style="text-align: center;"><b>\$207</b></p>  <p style="text-align: center;"><b>HP13-1507A Crankcase Cover Fits 1509A</b></p>	<p style="text-align: center;"><b>\$209</b></p>  <p style="text-align: center;"><b>HP15-1507A Bearing Clip Fits All</b></p>
<p style="text-align: center;"><b>\$211</b></p>  <p style="text-align: center;"><b>HP17-1507A Crankshaft</b></p>	<p style="text-align: center;"><b>\$212</b></p>  <p style="text-align: center;"><b>HP18-1507A HP18-1512C (Same) Needle Bearing</b></p>	<p style="text-align: center;"><b>\$214</b></p>  <p style="text-align: center;"><b>HP20-1507A Flange</b></p>	<p style="text-align: center;"><b>\$216</b></p>  <p style="text-align: center;"><b>HP22-1507A Bolt Flange Allen Key 8 x 65</b></p>
<p style="text-align: center;"><b>\$217</b></p>  <p style="text-align: center;"><b>HP23-1507A HP23-1509A Connect Rod</b></p>	<p style="text-align: center;"><b>\$218</b></p>  <p style="text-align: center;"><b>(HP23-27-1507A/ 1509A) Conrod Unit</b></p>	<p style="text-align: center;"><b>\$219</b></p>  <p style="text-align: center;"><b>HP24-1507A Fix Pin</b></p>	<p style="text-align: center;"><b>\$220</b></p>   <p style="text-align: center;"><b>HP25-1507A Plunger Rod</b>  <b>Modified HP25- 1507A Plunger Rod</b></p>
<p style="text-align: center;"><b>\$221</b></p>  <p style="text-align: center;"><b>HP25-30-1512A HP25-30-1509A HP25-30-1507A Plunger Assembly</b></p>	<p style="text-align: center;"><b>\$223</b></p>  <p style="text-align: center;"><b>Water Checking Flake HP27-1507A</b></p>	<p style="text-align: center;"><b>\$224</b></p>  <p style="text-align: center;"><b>Ceramic Plunger Fits HP28-1509A HP28-1507A</b></p>	<p style="text-align: center;"><b>\$226</b></p>  <p style="text-align: center;"><b>HP30-1507A Plunger Fix Nut</b></p>

<b>\$228</b>			<b>\$229</b>
			
<b>HP31-38-1507A Plunger Seal Kit Set of 3</b>			<b>HP32-1507A/1509A Locating Ring</b>
<b>\$233</b>	<b>\$234</b>	<b>\$235</b>	<b>\$236</b>
			
<b>HP35-1507A/1509A Compact Ring Seal</b>	<b>HP36-1507A Compaction Flake Water Seal</b>	<b>HP41-53-1507A Adjusting Pressure Regulator</b>	<b>HP37-1507A Seal – Fit – HP37-1509A</b>
<b>\$238</b>	<b>\$240</b>	<b>\$241</b>	<b>\$242</b>
			
<b>HP39-1507A Pressure Adjuster Handle Cover</b>	<b>HP42-1507A Pressure Adj. Handle</b>	<b>HP43-1507A Pressure Adjusting Seat</b>	<b>HP44-1507A Upper Washer Spring</b>
<b>\$243</b>	<b>\$244</b>	<b>\$245</b>	<b>\$246</b>
			
<b>Pressure Adjust Spring HP45-1507A</b>	<b>HP46-1507A Under Washer Spring</b>	<b>Water Return Valve Rod HP47-1507A</b>	<b>SP07 Unloader Valve HP47-53-1507A</b>

<p><b>\$249</b></p>  <p><b>HP50-1507A Water Return Valve Jacket</b></p>	<p><b>\$252</b></p>  <p><b>HP53-1507A Water Return Valve Core</b></p>	<p><b>\$253</b></p>  <p><b>Water Return Valve Seat HP54-1507A</b></p>	<p><b>\$256</b></p>  <p><b>HP57-1507A Water Outlet Tee Connect</b></p>
<p><b>\$258</b></p>  <p><b>HP59-1507A Fix Blot Outlet Tee</b></p>	<p><b>\$261</b></p>  <p><b>HP62-1507A Water Inlet Tee</b></p>	<p><b>\$265</b></p>  <p><b>HP66-1507A Water Inlet Connector</b></p>	<p><b>\$266</b></p>  <p><b>HP67-1507A Screw Cap</b></p>
<p><b>\$267</b></p>  <p><b>HP68-1507A Water Inlet Swivel Nut</b></p>	<p><b>\$268</b></p>  <p><b>HP70-79-1507A 3/8" Q.D. Detergent One Piece</b></p>	<p><b>\$269</b></p>  <p><b>Water Shoot Tube HP80-1507A</b></p>	<p><b>\$271</b></p>  <p><b>HP82-85-1507A QD Chemical Injector</b></p>
<p><b>\$273</b></p>  <p><b>HP83-1507A Spring Water Outlet Cone</b></p>	<p><b>\$274</b></p>  <p><b>Water Outlet Cone Valve HP84-1507A</b></p>	<p><b>\$277</b></p>  <p><b>HP88-1507A Washer Check Valve</b></p>	<p><b>\$278</b></p>  <p><b>HP89-1507A Check Valve Stopper</b></p>

<p style="text-align: center;"><b>\$279</b></p>  <p style="text-align: center;"><b>Spring Check Valve (Fits All) HP90-1507A</b></p>	<p style="text-align: center;"><b>\$283</b></p>  <p style="text-align: center;"><b>HP93-1507A Check Valve Cap</b></p>	<p style="text-align: center;"><b>\$284</b></p>  <p style="text-align: center;"><b>HP94-1507A Cylinder Bolts Fits HP94-1509A 6X55m</b></p>	<p style="text-align: center;"><b>\$285</b></p>  <p style="text-align: center;"><b>HP95-1507A Thermal Protect Valve</b></p>
<p style="text-align: center;"><b>\$286</b></p>  <p style="text-align: center;"><b>HP96-1507A Pressure Gauge C/W Adaptor</b></p>	<p style="text-align: center;"><b>\$287</b></p>  <p style="text-align: center;"><b>HP97-1507A SP01 3/8" Quick Coupling</b></p>	<p style="text-align: center;"><b>\$288</b></p>  <p style="text-align: center;"><b>HP98-1507A SP10 Pump Inlet Filter</b></p>	<p style="text-align: center;"><b>\$289</b></p>  <p style="text-align: center;"><b>HP40-57-1507A Pressure Regulator</b></p>
<p style="text-align: center;"><b>\$291</b></p>  <p style="text-align: center;"><b>HP99-1507A 3/8" Quick Disconnect</b></p>	<p style="text-align: center;"><b>\$292</b></p>  <p style="text-align: center;"><b>HP100-1507A 1/4" Quick Disconnect</b></p>	<p style="text-align: center;"><b>\$293</b></p>  <p style="text-align: center;"><b>HP101-1507A 1/4" Quick Disconnect</b></p>	<p style="text-align: center;"><b>\$296</b></p>  <p style="text-align: center;"><b>HP106-1507A SP28 One Touch Disconnect 1/4"</b></p>
<p style="text-align: center;"><b>\$300</b></p>  <p style="text-align: center;"><b>HP109-1507A 3/8" Swivel Quick Disconnect</b></p>	<p style="text-align: center;"><b>\$301</b></p>  <p style="text-align: center;"><b>HP110 - 1507A 3/8" One Touch Disconnect</b></p>	<p style="text-align: center;"><b>\$302</b></p>  <p style="text-align: center;"><b>HP111-1507A 3/8" Male Quick Disconnect Tip</b></p>	<p style="text-align: center;"><b>\$303</b></p>  <p style="text-align: center;"><b>HP112-1507A 1/4" Thermal Protect Valve</b></p>



<p><b>\$304</b></p>  <p><b>HP113-1507A Turbo Nozzle Connector</b></p>	<p><b>\$310</b></p>  <p><b>1/4" Male Disconnect Tip HP114-1507A</b></p>	<p><b>\$312</b></p>  <p><b>HP116-1507A Turbo Nozzle 040 Assembly</b></p>	<p><b>\$321</b></p>  <p><b>HP124-1507A Adapter for 22WD, 30WD</b></p>
<p><b>\$322</b></p>  <p><b>HP125-1507A Outlet Hose Connector</b></p>	<p><b>\$340</b></p>  <p><b>HP06-1507A Crankcase Cover Fits 1509A</b></p>	<p><b>\$341</b></p>  <p><b>HP17-1509A Crankshaft</b></p>	<p><b>\$342</b></p>  <p><b>HP20-1509A Flange</b></p>
<p><b>\$343</b></p>  <p><b>HP86-1512A HP86-1509A Cylinder</b></p>	<p><b>\$351</b></p>  <p><b>HP20 - 1512C Flange No 2</b></p>	<p><b>\$352</b></p>  <p><b>HP21-1512C Crankshaft Oil Seal</b></p>	<p><b>\$353</b></p>  <p><b>HP40-66-1512C Pressure Regulator Assembly</b></p>
<p><b>\$354</b></p>  <p><b>HP117-1512C Pressure Switch Assembly</b></p>	<p><b>\$355</b></p>  <p><b>HP17-1512C</b></p>	<p><b>\$356</b></p>  <p><b>HP40-78-1507A Water Inlet Assembly</b></p>	<p><b>\$357</b></p>  <p><b>HP104-SP12 By-Pass Valve</b></p>






<p style="text-align: center;"><b>\$360</b></p>  <p style="text-align: center;"><b>HP11-1807A Crankcase</b></p>	<p style="text-align: center;"><b>\$361</b></p>  <p style="text-align: center;"><i>Extension Lance Kit 36 inch</i></p> <p style="text-align: center;"><b>HP-Lance-ELA03</b></p>		
<p style="text-align: center;"><b>\$362</b></p>  <p style="text-align: center;"><b>HP13-1807A Crankshaft Cover</b></p>	<p style="text-align: center;"><b>\$363</b></p>  <p style="text-align: center;"><b>HP17-1807A Crankshaft</b></p>	<p style="text-align: center;"><b>\$364</b></p>  <p style="text-align: center;"><b>HP21-1807A Oil-Seal Flange</b></p>	<p style="text-align: center;"><b>\$365</b></p>  <p style="text-align: center;"><b>HP23-1807A Conrod</b></p>
<p style="text-align: center;"><b>\$366</b></p>  <p style="text-align: center;"><b>HP23-27-1807A Conrod</b></p>	<p style="text-align: center;"><b>\$367</b></p>  <p style="text-align: center;"><b>HP06-1807A Crankcase Cover</b></p>	<p style="text-align: center;"><b>\$368</b></p>  <p style="text-align: center;"><b>HP20-1807A Flange № 6</b></p>	<p style="text-align: center;"><b>\$370</b></p>  <p style="text-align: center;"><b>Needle Roller Bearing HP18-1807A</b></p>
<p style="text-align: center;"><b>\$371</b></p>  <p style="text-align: center;"><b>HP25-1807A Plunger Rod</b></p>	<p style="text-align: center;"><b>\$372</b></p>  <p style="text-align: center;"><b>H2O Checking Flake To Fit 1807A Pump HP27-1807A</b></p>	<p style="text-align: center;"><b>\$373</b></p>  <p style="text-align: center;"><b>HP28-1807A Ceramic Plunger</b></p>	<p style="text-align: center;"><b>\$375</b></p>  <p style="text-align: center;"><b>HP31-38-1807A Sealing Plunger Set</b></p>
<p style="text-align: center;"><b>Modified HP25-1807A Plunger Rod</b></p> 			

<p style="text-align: center;"><b>\$377</b></p>  <p style="text-align: center;"><b>HP32-1807A Locating Ring</b></p>	<p style="text-align: center;"><b>\$380</b></p>  <p style="text-align: center;"><b>HP35-1807A Compact Ring Seal</b></p>	<p style="text-align: center;"><b>\$381</b></p>  <p style="text-align: center;"><b>HP36-1807A Compaction Flake Water Seal</b></p>	<p style="text-align: center;"><b>\$382</b></p>  <p style="text-align: center;"><b>HP37-1807A U-Packing Oil Seal</b></p>
<p style="text-align: center;"><b>\$383</b></p>  <p style="text-align: center;"><b>HP38-1807A 'U' Packing Seat</b></p>	<p style="text-align: center;"><b>\$384</b></p>  <p style="text-align: center;"><b>HP87-91-1807A Check Valve Assly</b></p>	<p style="text-align: center;"><b>\$390</b></p>  <p style="text-align: center;"><b>HP02-1812C Oil Gauge New Type</b></p>	<p style="text-align: center;"><b>\$395</b></p>  <p style="text-align: center;"><b>HP20-1812C Flange No 3</b></p>
<p style="text-align: center;"><b>\$397</b></p>  <p style="text-align: center;"><b>HPE-2200-ROTAT Rotator Shaft C/W Bearings</b></p>	<p style="text-align: center;"><b>\$398</b></p>  <p style="text-align: center;"><b>HPE-3000-ROTAT</b></p>	<p style="text-align: center;"><b>\$399</b></p>  <p style="text-align: center;">                     HP86-1807A                      HP86-1812C } <b>Cylinder</b> </p>	<p style="text-align: center;"><b>\$411</b></p> <p style="text-align: center;"><b>HP-HOSE/1500C1 Hose 1/4" 3200 PSI</b></p>
<p style="text-align: center;"><b>\$412</b></p> <p style="text-align: center;"><b>HP-UBL02 Underbody Cleaning Lance</b></p>	<p style="text-align: center;"><b>\$413</b></p>  <p style="text-align: center;"><b>HPE-2200-R/COV - Rear End Cover</b></p>		



<b>\$414</b>	<b>\$416</b>	<b>\$436</b>	<b>\$437</b>
 <p><b>HP-HLH01 – High – Low – Nozzle Holder</b></p>	<p>On the board No photo</p>	 <p><b>HPE-2200-C/CWT – Centrifugal Switch</b></p>	 <p><b>HPE-2200-GOV Governor Assly</b></p>
<b>\$438</b>	<b>\$439</b>	<b>\$452</b>	
 <p><b>HPE-2200-DRCOV Aluminium End Cover</b></p>	 <p><b>HPE-2200-CN/BOX Connector Box Cover Case</b></p>	<p>HL30B1 } HL80A } -0091 Suction Hose</p>	
<b>\$494</b>	<b>\$495</b>	<b>\$496</b>	<b>\$512</b>
<p>On the board No photo</p>			
<p><b>HP123-1507A 61 Outlet Connector – New</b></p>	<p><b>HP34-48-1507A Pressure Regulator Series II</b></p>	<p><b>HP122-1507A Outlet Quick Connector</b></p>	<p><b>HL80A-0011 Crankcase Cover</b></p>
<b>\$570</b>	<b>\$579</b>	<b>\$600</b>	
<p><b>HL80A-0086 V-Pulley</b></p>	<p><b>HL80A-0096 Suction Strainer Assly</b></p>		<p><b>HL80A-59-85 Unload Assly</b></p>

HP-TELEWAND			
 <p>Telescopic Wand Lance</p>		 <p>Operating Handle for Hand Sprayer HP-SK10- Handle</p>	

	PG 04/5000	HIGH PRESSURE GUN 3600 PSI
		HIGH PRESSURE GUN. 5000PSI – 345BAR (FIXED LANCE)
	HP-PSP56/Hose - 014	HP Hose Φ8.5 x 14mm x 30m. 60mpa (Fits Piston Pulley Pumps)
	HP-Hose/10m	HP Hose 10m 3600 PSI (fits 3600)
	HP-Hose/2200C	HP Hose 10m 3200 PSI (fits 2200C/2700)
	HP-Hose/8mm	HP Hose 10m 3200 PSI (fits 3000C/3200)
	HP-Hose/10m-HD	Heavy Duty HP Hose 43100 PSI
	HP-Hose/20m	HP Hose 20m 3600 PSI (fits 3600)
	HP-Hose/Outlet	White Outlet Hose
	HP-LANCE/FOAM - 025	FOAM GUN
	<b>NEW</b> HP-LANCE/V1.1	VARIABLE LANCE FOR 2700PSI
	<b>NEW</b> HP-LANCE/V1.2	VARIABLE LANCE FOR 3600PSI