

TEMPERATURE MEASUREMENT LABORATORY

1. Materials needed:

ASTM Hg thermometer
Regular Hg or alcohol thermometer (keep the same one for the entire temp lab)
Davis weather station temperature probe
Thermocouple, bead thermistor, or platinum resistance thermometer
Dewar
Wind tunnel
Stopwatch
Ice
Electric kettle
Water
Paper towels

2. Objectives

The objectives of this lab are to familiarize you with some of the various types of temperature sensors in current use, to calibrate them (and hence to recognize the relationship between data quality and instrument calibration), and to evaluate the impact of ventilation and time response on temperature measurement.

In this lab, you will also calibrate the Davis temperature sensor for your weather station.

3. Tasks

3.1 Calibrations

3.1.1 Calibrate the **regular** Hg thermometers against the **ASTM** Hg thermometers (ASTM stands for “American Society for Testing and Materials”, which is the non-profit organization that writes standards for materials and measurements.) **RECORD THE ASTM CALIBRATION CERTIFICATE INFORMATION**, you will *need* this to calculate a total uncertainty in the true value of temperature relative to what the NIST measurement would be.

Establish five different temperatures of water in a dewar, spanning from 0 to LESS than 30C. **NOTE THE ASTM THERMOMETERS CAN’T EXCEED 30C.** To do this, start with ice water as your lowest temperature. Then add small amounts of hot water (from the electric kettle) to create four higher temperatures. Use the T indicated on the ASTM as the “true” T, and note the T indicated by the regular thermometer for each of the five different temperatures. *Note, the 5 temperatures used for calibration need not be the same for each sensor type, but the range should be similar.*

3.1.2 Again, use water at five different temperatures from freezing to 30°C in a dewar, and your now calibrated *regular* thermometers to generate a calibration for your Davis station temperature Probe AND one of the following sensors:

- (a) thermocouple (type K or type E, note which one!)
- (b) bead thermistor

These sensors' calibrations (accuracy) are now *tied* to the ASTM standard via the regular Hg thermometers. The idea here is that the ASTM thermometers are EXPENSIVE (~\$300 each) and should be preserved with care (i.e. minimal use) to maintain ultimate accuracy. You will estimate the precision of each sensor using linear regression analysis.

3.2 Time Response

Determine the time constant for the following:

- (1) your Davis temperature probe
- (2) a regular Hg thermometer

You will accomplish this goal by measuring *the decay in the difference between the temperature of the various thermometers and ambient temperature* ($T_{\text{probe}} - T_{\text{ambient}}$) as a function of time since the environmental change (hot water \rightarrow room air). Don't forget to note the ambient T of the room! If time allows, you could also try examining the time response of a thermocouple at zero ventilation for comparison.

Procedure

1. Start with zero ventilation (i.e. fan on wind tunnel is off).
2. Heat the thermometric device to a temperature far above ambient (e.g. ~ 50 C or higher) using a dewar filled with hot water, **then quickly dry the probe (WHY? – discuss in your report)** and insert it into a wind tunnel for constant ventilation rates.
3. One group member should be operating a stopwatch and indicating time intervals at which another group member reads off the temperature value. A third group member, or the member responsible for temperature reading, should record the value and time elapsed since insertion into the wind tunnel. **Record points at least every 5-10 seconds, the more points per decay the better the fit. Possibly, every 5 seconds may be necessary. You may want to record a faster rates early on, and then slower rates as the T reading approaches ambient.**
4. Repeat steps 2 - 4 for ***at least three different non-zero*** ventilation rates between 0 and 1 m/s, and one trial at a ventilation rate > 2 m/s. Establish a constant ventilation rate by adjusting the fan speed via the Variac dial, and use the needle gauge anemometer on the opposite end of the wind tunnel together with a stopwatch to determine the actual ventilation rate. Be sure to account for any initial offset in the needle, and simply divide the feet traveled (needle reading) by the time (e.g., 40 feet in 10 seconds would be a wind speed of 4 feet per second, which should then be converted into SI units of m s^{-1}).

Make sure you always have a measure of the ambient temperature for each response measurement.

4. Questions to address in the lab report

4.1 Sensor Calibrations and Total Uncertainty

4.1.1 From a linear regression analysis ($T_{\text{true}} = aT_{\text{Hg}} + b$), evaluate the accuracy of the regular Hg thermometer against the ASTM calibration, i.e. calibration of the regular Hg thermometer against the ASTM thermometer using regression ($T_{\text{ASTM}} = cT_{\text{Hg}} + d$). Discuss the degree to which they are in agreement. It is useful to show 1 representative figure.

4.1.2. Using the regular Hg thermometer as a transfer standard, what is the accuracy of each of the other transducers relative to the NIST standard based on your 5-point calibration? In your linear regression analysis, be sure to take the independent variable (x-axis) as the observed temperature, and the dependent variable (y-axis) as the standard temperature (NIST, ASTM, or regular Hg thermometer) in the regression).

- For the thermocouples, determine which type you used (K or E), and determine the best estimate of T based on the measured voltage by consulting the tables available online from a vendor, such as, Omega.com.
- For the thermistor, the output voltage was linearized to be 0.01V per degree Centigrade.

Evaluate the absolute accuracy of the non-standard transducers that you calibrated based on the NIST standard being the “true” temperature. You can do this using the propagation of error rules and combining the uncertainty of the ASTM Hg thermometer relative to NIST (the national standard from the “National Institute for Standards and Technology”) with the uncertainty of the transducers relative to the ASTM thermometer (see “TIPS” below and available on course web page).

4.1.3. Assuming that the ASTM and regular Hg thermometers are linear, how linear are the other transducers?

4.2 Time Response Analysis

3.2.1 Determine the 1/e decay time from a non-linear regression (or linear regression in log-space) analysis at each wind speed (i.e. the time for the difference between the thermometer reading and final (ambient) reading to reach 37% (1/e) of the initial difference between the thermometer reading and ambient). Note the estimate of the uncertainty on the time constant. For the non-linear regression, assume a form like

$$(T - T_{\text{ambient}}) = (T_0 - T_{\text{ambient}})e^{-t/\tau}$$
$$\Rightarrow (T - T_{\text{ambient}}) = ae^{-bt}$$

where T_0 is the first data point (hot), τ is the time constant.

4.2.2. For the transducers tested for time response, rank them in terms of time response. Does wind speed change the ranking? Show an example figure of the decays in temperature versus time in the wind tunnel.

4.2.3. Make a scatter plot of your measured time constants from 2.2 versus wind speed. Is there a relationship, and should there be? Discuss discrepancies between observed relationship and your expectations.

5. Incorporating Your Answers in the Report

In your report, you will be expected to summarize results succinctly in tables and or figures, however you must ALSO include descriptions of your results in the body of your report text as well. For example, from looking at the total error estimates determined from a propagation of errors associated with the calibration experiments, the thermometers should be ranked best to worst in a table (see example table below). Some values in the table should have an associated unit, please make sure to note that unit in your table. Just because you summarize a value in a table does NOT mean you don't need to introduce and discuss it within the body of your report!

Any figures and tables you decide to show should be *well labeled* – axis titles, with units, some way to differentiate between multiple curves, lines or other independent data sets, and a concise but clear and comprehensive figure caption.

Example Table for Summarizing Results (where Mercury will be relative to the ASTM and the transducers relative to the Mercury, the total error will be expressed relative to the NIST standard):

THERMOMETER	R^2	slope, A	intercept, B	A error	B error	Total Error	Rank
Mercury							
Davis							
Bead thermistor							
Thermocouple							
PRT							

ATMS 451 Temperature lab: Analysis Tips

General Instructions: In this first detailed lab, students often have trouble applying the theory in lecture notes to the practical problem. These extra notes are intended to alleviate that problem.

Use $T_{\text{true}} = aT_{\text{sensor}} + b$ to get a straight line fit, where T_{true} is the temperature measured by your working standard (NIST, ASTM, or regular thermometer) (which recall has its own uncertainty that we will deal with later). This will give errors s_a and s_b , so you quote the straight line fit in your report as:

$$T_{\text{true}} = (\text{slope} \pm s_{\text{slope}}) T_{\text{sensor}} + (\text{intercept} \pm s_{\text{intercept}})$$

You should have 5 pairs of T observations for each sensor relative to the regular Hg thermometer as well as the calibration of the regular Hg thermometer against the ASTM. You will also have an equation relating the ASTM thermometer to NIST. Each regression line should be stated in your report.

In the end you want to have a linear equation that relates each sensor to the NIST standard:

$$T_{\text{NIST}} = (A \pm s_A) T_{\text{sensor}} + (B \pm s_B) \quad (1)$$

From this equation you can propagate the error to obtain the error of each sensor relative to the NIST standard.

Calibration of the thermometers: For each of your transducers, you will have

$$T_{\text{Hg}} = (a \pm s_a) T_{\text{obs}} + (b \pm s_b) \quad (2)$$

where T_{obs} = the observations for each transducer (Davis, bead thermistor, thermocouple, or RTD).

You can use linear regression to get the fit in each case. However, T_{Hg} is not quite the “real” temperature, nor is T_{ASTM} ; it is related to the real, absolute temperature via the NIST-traceable calibration certificate data for the ASTM thermometer, i.e.,

$$T_{\text{NIST}} = (c \pm s_c) T_{\text{ASTM}} + (d \pm s_d) \quad (3)$$

and the regular Hg thermometer is related to the ASTM by:

$$T_{\text{ASTM}} = (e \pm s_e) T_{\text{Hg}} + (f \pm s_f) \quad (4)$$

Thus, to get a total uncertainty for each sensor about the true temperature value (T_{NIST}), you must propagate uncertainty through the linear relationship you determine for each transducer (Equation 1). In Equation 1, A and B will be a function of a, b, c, d, e and f that you determined from the linear regression analysis.

Use the “combination of errors formula” applied to Equation 1 to get a total standard error in the sensor T relative to the calibrated Hg thermometer, i.e.,

$$S_{T_{NIST}}^2 = \left(\frac{\delta T_{NIST}}{\delta A}\right)^2 S_A^2 + \left(\frac{\delta T_{NIST}}{\delta T_{obs}}\right)^2 S_{obs}^2 + \left(\frac{\delta T_{NIST}}{\delta B}\right)^2 S_B^2 \quad (5)$$

From (5) and (1):

$$S_{T_{NIST}}^2 = \overline{T_{obs}^2} S_A^2 + S_B^2 + A^2 S_{obs}^2 \quad (6)$$

where:

$$\overline{T_{obs}} = (\sum T)/5$$

for a total of 5 measurements for each sensor.

The idea here is as follows. Suppose we used one of the transducers to measure ambient T. The question is how uncertain is our measured T relative to that if we had used a better calibrated Hg thermometer. We can get S_A^2 and S_B^2 from the regression analysis. Since we did not necessarily measure each T multiple times, we must get an estimate of $S_{T_{obs}}^2$, from the average deviation of the measurements from the line of best fit.

$$S_{T_{obs}}^2 = \frac{1}{N-2} \sum_i^N (T_{obs(i)} - T_{fit(i)})^2 \quad (7)$$

T_{fit} is obtained by rearranging your linear regression equation and solving for the predicted T_{obs} for each T_{Hg} value. The above approach should be repeated for each sensor, including the ASTM and regular Hg thermometers.

Now if we look at the NIST calibration for the ASTM thermometer and the linear fit given by (2), we can use the same technique to calculate the error relative to the NIST temperature, i.e. the “real” temperature:

$$S_{T_{NIST}}^2 = \left(\frac{\partial T_{NIST}}{\partial C}\right)^2 S_C^2 + \left(\frac{\partial T_{NIST}}{\partial D}\right)^2 S_D^2 + \left(\frac{\partial T_{NIST}}{\partial T_{ASTM}}\right)^2 S_{T_{ASTM}}^2 \quad (8)$$

Evaluating the partial derivatives, we have:

$$S_{T_{NIST}}^2 = \overline{T_{ASTM}}^2 S_C^2 + S_D^2 + C^2 S_{T_{ASTM}}^2 \quad (9)$$

Here $\overline{T_{ASTM}}$ is the average of the (five) samples from the ASTM thermometer recorded when calibrating the regular Hg thermometers.

The ultimate goal is to get $S_{T_{NIST}}^2$ for each sensor type, which is the expected level uncertainty in the measurements made for a given sensor type about the true (NIST) temperature. Comment on the uncertainty of a sensor in terms of its total error and how far removed it was from the true NIST standard.